Portable EV Charger Instructions



It is recommended to read the instructions before use

CATALOG

Safety instructions - - - 1

Product Overview

Brief description - - - 2

Size of Charging Control Box - - - 3

Product parameters

Type 2 Parameter introduction - - - 3

Type 1 Parameter introduction - - - 4

GB/T Parameter introduction - - - 5

TS-NACS Parameter introduction - - - 6

Operating Instructions

Pre-use preparation - - - 7

Charging steps

Standby status - - - 7

Waiting for card swipe status - - - 7

Start-up device - - - 8

Start charging - - - 9

Stop charging - - - 9

Key operation instructions

How to set the charging current - - - 11

How to set time delay charging - - - 12

How to set the timing charging - - - 12

How to access the menu page - - - 13

Menu page basic key operation - - - 13

Dynamic Load Balancing Page - - - 15

DLB Charging Plan A(for single phase) - - - 15

DLB Charging Plan A(for three phase) - - - 16

DLB Charging Plan B(three phase only) - - - 17

How to view and adjust DLB settings - - - 19

Single-phase Wiring Instructions - - - 20

Three-phase wiring instructions - - - 21

How to use the App - - - 22

Control Box LCD Display - - - 23

Installation and operation instructions - - - 26

Common Troubleshooting - - - 27

Charging Status and Indicator Light - - - 28

Safety instructions

Warning : The charging station must be grounded (PE) in order to use it properly

Warning : Do not place flammable, explosive or combustible materials, chemicals, combustible vapors or other hazardous materials near the charging station.

Warning : Keep the charging plug head clean and dry, if dirty, please wipe it with a clean and dry cloth, it is strictly forbidden to touch the charging plug core by hand when it is charged

Warning: It is strictly forbidden to use the charging station when the charging plug or charging cable is defective, cracked, worn, broken or when the charging cable is exposed

Warning : Do not attempt to disassemble, repair or modify the charging station. If you need to repair or modify it, please contact the relevant staff. improper operation may cause the charging station damage, water leakage, leakage of electricity, short circuit, electric shock and other risks

Warning : Use with caution during thunderstorms

Warning : Children should not approach or use the charging station during the charging process to avoid electric shock

Warning : Do not drive the car while it is charging. You can only start charging When the car is stationary. For hybrid Cars, please turn off the engine before charging

Warning : In case of emergency during the operation of the product, press the emergency stop button immediately to cut off all input and output power

Warning : The use of the charging station is prohibited in the following cases and the manufacturer should be contacted immediately:

* Bad charging station shell
* When the charging cable on the charging station is damaged, cracked, frayed, broken, etc.
* Lightning strikes charging station
* Accidents or fires near charging stations
* Water in the charging station
* The length of the charging cable on charging station is not long enough to connect to the car, an extension cable needs to be installed

Product Overview

Brief description :

This product is used for electric vehicle AC charging, the product design is highly simple, divided into Type2,Type1,GB/T, TS-NACS,four kinds of specifications.It is equipped with swipe card and plug-and-play charging methods and multiple safety protection functions. with good dustproof and waterproof function, can be operated safely in outdoor.



Type 2 Parameter introduction

Type 2 IEC 62196-2															
Power Rating	7.6kW					11kW					22kW				
Load balancing	/	/	●			/	/	●			/	/	●		
APP	/	●	●			/	●	●			/	●	●		
RFID Card	/	●	●			/	●	●			/	●	●		
Type A RCD	●	/	●	/	/	●	/	●	/	/	●	/	●	/	/
Type B RCD	/	●	/	●	●	/	●	/	●	●	/	●	/	●	●
Leakage Protection Value	TypeA: AC 30mA TypeB: AC 30mA+DC 6mA														
Power supply system	Single Phase					Three Phase					Three Phase				
Rated voltage	85V-264V					380V±20%					380V±20%				
Rated current	8-10-13-16-20-25-32A					8-10-13-16A					8-10-13-16-20-25-32A				
Input Frequency	50Hz/60Hz					50Hz/60Hz					50Hz/60Hz				
Charger Plug	IP66					IP66					IP66				
Charger Box	IP66					IP66					IP66				
Working temperature	-35℃ ~ +55℃					-35℃ ~ +55℃					-35℃ ~ +55℃				
Storage temperature	-40℃ ~ +80℃					-40℃ ~ +80℃					-40℃ ~ +80℃				
Standby power	<3W					<3W					<3W				
Working humidity	5% ~ 95% non-condensation					5% ~ 95% non-condensation					5% ~ 95% non-condensation				
Cable Specification	3G 6mm²+1*0.5mm²					5G 2.5mm²+1*0.5mm²					5G 6mm²+1*0.5mm²				

Control box function:
1.Leakage protection (restart recovery)
2.Overvoltage and undervoltage protection(self-test recovery)
3.Lightning protection
4.Overcurrent protection
5.Overheat protection
6.Grounding protection
7.RFID card function(can be set according to user needs)
8.Appointment Time
9.WIFI

Product Performance:
1.Charging plug according to IEC 62196-2 standard
2.Charging control box in accordance with IEC61851 control principle
3.Insulation resistance:>1000Ω
4.Terminal temperature rise:<50K
5.Mechanicallife: Charging Plug plugging and unplugging times (Non operating state)>10000 times
6.External impact:Charging Station Plug can withstand the 1-meter drop and 2 tons of vehicle crushing
7.Altitude:≤2000m
8.With emergency stop function

Type 1 Parameter introduction

Type 1 SAE J1772														
Power Rating	7.6kW					9.6kW					12kW				
Load balancing	/		/		●	/		/		●	/		/		●
APP	/		●		●	/		●		●	/		●		●
RFID Card	/		●		●	/		●		●	/		●		●
Type A RCD	●	/	●	/	/	●	/	●	/	/	●	/	●	/	/
Type B RCD	/	●	/	●	●	/	●	/	●	●	/	●	/	●	●
Leakage Protection Value	TypeA:(60Hz)AC20mA/(50Hz)AC30mA TypeB: AC 30mA+DC 6mA														
Power supply system	Level 1 and Level 2					Level 1 and Level 2					Level 1 and Level 2				
Rated voltage	85V-264V					85V-264V					85V-264V				
Rated current	8-10-13-16-20-25-32A					8-10-13-16-20-25-32-40A					8-10-13-16-20-25-32-40-50A				
Input Frequency	50Hz/60Hz					50Hz/60Hz					50Hz/60Hz				
Charger Plug	IP66					IP66					IP66				
Charger Box	IP66					IP66					IP66				
Working temperature	-35℃ ~ +55℃					-35℃ ~ +55℃					-35℃ ~ +55℃				
Storage temperature	-40℃ ~ +80℃					-40℃ ~ +80℃					-40℃ ~ +80℃				
Standby power	<3W					<3W					<3W				
Working humidity	5% ~ 95% non-condensation					5% ~ 95% non-condensation					5% ~ 95% non-condensation				
Cable Specification	3G 6mm²+1*0.5mm²					3G 8mm²+2*0.5mm²					3G 10mm²+2*0.5mm²				

Control box function:
1.Leakage protection (restart recovery)
2.Overvoltage and undervoltage protection(self-test recovery)
3.Lightning protection
4.Overcurrent protection
5.Overheat protection
6.Grounding protection
7.RFID card function(can be set according to user needs)
8.Appointment Time
9.WIFI

Product Performance:
1.Charging plug according to SAE J1772 standard
2.Charging control box in accordance with IEC61851 control principle
3.Insulation resistance:>1000Ω
4.Terminal temperature rise:<50K
5.Mechanicallife: Charging Plug plugging and unplugging times (Non operating state)>10000 times
6.External impact:Charging Station Plug can withstand the 1-meter drop and 2 tons of vehicle crushing
7.Altitude:≤2000m
8.With emergency stop function

GB/T Parameter introduction

GB/T															
Power Rating	7.6kW					11kW					22kW				
Load balancing	/	/	●			/	/	●			/	/	●		
APP	/	●	●			/	●	●			/	●	●		
RFID Card	/	●	●			/	●	●			/	●	●		
Type A RCD	●	/	●	/	/	●	/	●	/	/	●	/	●	/	/
Type B RCD	/	●	/	●	●	/	●	/	●	●	/	●	/	●	●
Leakage Protection Value	TypeA: AC 30mA TypeB: AC 30mA+DC 6mA														
Power supply system	Single Phase					Three Phase					Three Phase				
Rated voltage	85V-264V					380V±20%					380V±20%				
Rated current	8-10-13-16-20-25-32A					8-10-13-16A					8-10-13-16-20-25-32A				
Input Frequency	50Hz/60Hz					50Hz/60Hz					50Hz/60Hz				
Charger Plug	IP66					IP66					IP66				
Charger Box	IP66					IP66					IP66				
Working temperature	-35℃ ~ +55℃					-35℃ ~ +55℃					-35℃ ~ +55℃				
Storage temperature	-40℃ ~ +80℃					-40℃ ~ +80℃					-40℃ ~ +80℃				
Standby power	<3W					<3W					<3W				
Working humidity	5% ~ 95% non-condensation					5% ~ 95% non-condensation					5% ~ 95% non-condensation				
Cable Specification	3G 6mm²+1*0.5mm²					5G 2.5mm²+1*0.5mm²					5G 6mm²+1*0.5mm²				

Control box function:
1.Leakage protection (restart recovery)
2.Overvoltage and undervoltage protection(self-test recovery)
3.Lightning protection
4.Overcurrent protection
5.Overheat protection
6.Grounding protection
7.RFID card function(can be set according to user needs)
8.Appointment Time
9.WIFI

Product Performance:
1.Charging plug according to GB/T20234 standard
2.Charging control box in accordance with IEC61851 control principle
3.Insulation resistance:>1000Ω
4.Terminal temperature rise:<50K
5.Mechanicallife: Charging Plug plugging and unplugging times (Non operating state)>10000 times
6.External impact:Charging Station Plug can withstand the 1-meter drop and 2 tons of vehicle crushing
7.Altitude:≤2000m
8.With emergency stop function

TS-NACS Parameter introduction

TS-NACS									
Power Rating	7.6kW			9.6kW			12kW		
Load balancing	/	/	●	/	/	●	/	/	●
APP	/	●	●	/	●	●	/	●	●
RFID Card	/	●	●	/	●	●	/	●	●
Type B RCD	●	●	●	●	●	●	●	●	●
Leakage Protection Value	TypeB: AC 30mA+DC 6mA								
Power supply system	Level 1 and Level 2			Level 1 and Level 2			Level 1 and Level 2		
Rated voltage	85V-264V			85V-264V			85V-264V		
Rated current	8-10-13-16-20-25-32A			8-10-13-16-20-25-32-40A			8-10-13-16-20-25-32-40-50A		
Input Frequency	50Hz/60Hz			50Hz/60Hz			50Hz/60Hz		
Charger Plug	IP66			IP66			IP66		
Charger Box	IP66			IP66			IP66		
Working temperature	-35℃ ~ +55℃			-35℃ ~ +55℃			-35℃ ~ +55℃		
Storage temperature	-40℃ ~ +80℃			-40℃ ~ +80℃			-40℃ ~ +80℃		
Standby power	<3W			<3W			<3W		
Working humidity	5% ~ 95% non-condensation			5% ~ 95% non-condensation			5% ~ 95% non-condensation		
Cable Specification	3G 6mm²+2*0.5mm²			3G 8mm²+2*0.5mm²			3G 10mm²+2*0.5mm²		

Control box function:
1.Leakage protection (restart recovery)
2.Overvoltage and undervoltage protection(self-test recovery)
3.Lightning protection
4.Overcurrent protection
5.Overheat protection
6.Grounding protection
7.RFID card function(can be set according to user needs)
8.Appointment Time
9.WIFI

Product Performance:
1.Charging plug according to TS-NACS standard
2.Charging control box in accordance with IEC61851 control principle
3.Insulation resistance:>1000Ω
4.Terminal temperature rise:<50K
5.Mechanicallife: Charging Plug plugging and unplugging times (Non operating state)>10000 times
6.External impact:Charging Station Plug can withstand the 1-meter drop and 2 tons of vehicle crushing
7.Altitude:≤2000m
8.With emergency stop function

Operating Instructions

Pre-use preparation :


1. Ensure that there are no open flames around the equipment and that the surrounding space is not blocked
2. Ensure that the equipment casing and charging cable are not damaged
3. Ensure proper maintenance of equipment
4. Make sure the emergency stop button is popped up, if it has been pressed, Please rotate the button clockwise to turn the button back.

Charging steps :

(1) Standby status


When the charging station in standby mode, the interface shows that the device is ready for charging,as shown in the figure below:

The indicator light on the wallbox is green and always on.



(2) Waiting for card swipe status

After park your car near the charging station, take the charging plug from the plug holder,set the charging current,then insert the charging plug into the connector of the electric vehicle.Please make sure that the plug is inserted in place and the connection is safe and reliable.When the charging plug monitors that the charging plug is inserted correctly,It will enter the status of identity verification, as shown in the following figure:



(3) Start-up device

Use RFID cards to authorize the use of charging station


START



(4) Start charging

1. The device starts charging and the interface displays the charging status and information parameters as shown in the following figure:

2. The indicator light on the case (for Wi-Fi function only) is green breathing;



(5) Stop charging


1. When the vehicle is fully charged, the charging station will automatically stop charging; in case of emergency, you can manually press the Emergency stop button to cut off power.

2. RFID card can also be used to authorize stopping the use of the charging station during charging;

STOP



3. The display is as follows



4. The indicator light on the case (for Wi-Fi function only) is green flashing or green always on;

Key Operation Instructions

(1) How to set the charging current

1.When the charging plug is not inserted in the car, press the button A on the panel to adjust the charging current, After use the RFID card to turn on the charging, the device will output the corresponding current.the current setting range is determined by the max charging power of charging station ,7.6kW and 22kW version can set the curent of 8-10-13-16-20-25-32A,11kW version can set the current of 8-10-13-16A.



(2) How to set the delay time charging

1.When the charging plug is not inserted in the car,touch the button on the panel shows below to set the delayed charging time,after swiping the card and turn on the charger,the device will start charging after "X" hours according to the delayed time set.which means the charger will start charging after "X" hours,and the range can be set from 0 to 15 hours (each touch increase an hour);



(3) How to set the charging time.

1.Touch the button on the panel shows below to modify the timing charging , after swiping the card and turn on the charger,The device will keep charging for "X"Hours according to the time you set.which means the charger will keep charging for "X" hours,after the time runs out,the charger will stop charging. you can set the time from 0 to 15 hours (each touch increase an hour);



(4) How to access the menu page

1. Press the area in the picture below for 5 seconds to enter the setting menu （without RFID function version charging station）

2. Press the area in the picture below for 5 seconds ,then swip the RFID card to enter the settings menu （with RFID function version charging station）



(5) Menu page basic key operation

1. Touch the panel icon area to upward, downward, enter, back and increase or decrease the parameters of the menu.
Note: When the Charging plug is plugged in, it is not possible to enter the charging plan and load balance setting function. Need to pull out the charging plug to operate.



2.Menu - Charging plan

Set Current：Adjust Current

Delay Start：Set Delay Time


Charge Time：Set Charging Time



3.Menu - Rfid Manage


Add Card：Add a blank RFID card to the charging station that can be used

Delete Card：Delete RFID that has already been added




4.Menu - Charge Log

Record the last 10 charging statuses for fault diagnosis




5.Menu - Setting

Hotkeys:Turn on and off the lock button to prevent others from operating it
CardID Check：Cancel or restart the use of RFID cards
Reset Wifi：Clear network configuration
Ground Check：To turn on and off the grounding (PE) detection, please use the charging station in the grounded (PE) state





6.Menu - About Device




(6) Dynamic Load Balancing Function (only for DLB function model):

Plan A (for single phase): DLB (Dynamic Load Balancing) is an intelligent power management technology. It monitors the current of household circuit in real time, takes the total current as the judgment basis, and automatically adjusts the output power of the charger. This ensures that the total current does not exceed its safe carrying limit, effectively avoiding tripping, equipment damage, and even potential safety hazards caused by overloading.







- **Total Current (user input)**

This parameter sets the maximum current capacity per phase (e.g., 80A) for the home circuit. It is adjustable from 8A to 99A, and any excess of the set value will cause the circuit breaker to trip.

- **Charging Current**

Charging Current: The real-time charging current when the charger working.


- **Home Appliance**


Total load of home appliances in the load circuit, excluding the charging station


- **Standby Current**

Standby Current = Total Current - Home Appliance - Charging Current.

Plan A (for three phase): DLB (Dynamic Load Balancing) is an intelligent power management technology. It monitors the current of each phase in the household three-phase circuit in real time, takes the maximum phase current among the three phases as the judgment basis, and automatically adjusts the output power of the charger. This ensures that the total current of each phase does not exceed its safe carrying limit, effectively avoiding tripping, equipment damage, and even potential safety hazards caused by overloading of any phase.







- **Total Current (user input)**

This parameter sets the maximum current capacity per phase (e.g., 80A) for the home circuit. It is adjustable from 8A to 99A, and any excess of the set value will cause the circuit breaker to trip.

- **Charging Current**

Charging Current: The real-time charging current when the charger working.

- **Home Appliance**

Total load of home appliances in the load circuit, excluding the charging station


- **Standby Current**


Standby Current = Total Current - Home Appliance - Charging Current.


- **home appliance max**


Max phase current of home appliances in three-phase loading detected by the electricity meter excluding the charging station


Plan B (three phase only): DLB is an intelligent power management technology. It monitors the total current of the three phases (L1/L2/L3) of a household in real time and dynamically adjusts the output power of the EV charger. This ensures maximum utilization of available power without exceeding the set maximum household current, while preventing tripping or overload caused by the simultaneous use of high-power electrical appliances.



















Standby Current > 0A:Indicates that there is remaining current available on this phase.
Standby Current ≤ 0A:Indicates that this phase is already at maximum load. Do not connect additional loads.





- **Household Current (user input)**

Total three-phase incoming current for household use. It can be adjust from 8A to 999A, according to your actual requirements.

- **Total Current (user input)**

This parameter sets the maximum current capacity per phase (e.g., 80A) for the home circuit. It is adjustable from 8A to 99A, and any excess of the set value will cause the circuit breaker to trip.

- **Charging Current sum**

The real-time charging current sum of 3 phase.


- **Home Appliance Sum**


Total current of home appliances in three-phase loading detected by the electricity meter excluding the charging station.


- **Standby Current Sum**


Total remaining available current in three-phase circuit;
Household Current sum - Home Appliance sum - Charging Current sum.






















How to view and adjust DLB settings?

T Tap to switch units (ones/tens/hundreds)




A Tap to increase value


D Tap to decrease value




Tap to save and go back



Single-phase Wiring Instructions



Three-phase wiring instructions




How to use the App

How to use the App (the device needs to have Wifi function,and Bluetooth function)

1.Please download the "Smart Life" (recommended) or the "Tuya Smart" APP on your cell phone. The APP icon as shown above.


Smart life tuya smart

2. After downloading, open the app, turn on your phone WiFi and Bluetooth, select Add Device, and follow the instructions to complete Add a new device,as shown below:




Control Box LCD Display

7.6kW/9.6kW/12kW interface as shown below





11kW/22kW interface as shown below




Control Box LCD Display

Single-phase







Ready to Charge




Swipe RFID Card




Charging




EMERGENCY STOP




Signal Failure




Under Voltage




Over Voltage




Leakage




Over Current




Over TEMP




Missing of PE Protection



Leakage Self Check




Relay Self Check




Load Balance Fault
(DLB Only)


Control Box LCD Display

Three-phase







Ready to Charge




Swipe RFID Card




Charging




EMERGENCY STOP




Signal Failure




Under Voltage




Over Voltage




Leakage




Over Current




Over TEMP




Missing of PE Protection



Leakage Self Check




Relay Self Check




Load Balance Fault
(DLB Only)


Installation and operation instructions




Step 1：According to the position of the holes on the metal Back mounting bracket, use an electric driller to drill holes in the corresponding positions . Please refer to the height in the photo below to determine the charger installation height. then put the expansion tube in the hole , and then use long screws fix the metal mounting bracket on the wall.



Step 2：After fixed the metal bracket to the wall, hang the charger on the bracket while using the screws to fix the Metal bracket underneath the charger to the wall.



Step 3：Install the charging plug holder in the position shown in the pics above



Step 4：Connect the power supply and make sure the charger can work properly

Common Troubleshooting

Fault name	Reason for failure	Recommendations
Over Voltage	AC input voltage is too high	1. Ask an electrician measure the input voltage of the charger's power distribution box
		2. If the actual voltage is over 264V for a short time, wait for the power system to restore itself to the normal voltage range.
		3. If the actual voltage is over 264V for a long time, please contact the local power supply department
		4. If the actual voltage of the electrical system in your home is less than 264V, please contact us;
Under Voltage	AC input voltage is too low	1. Ask an electrician measure the input voltage of the charger's power distribution box
		2. If the actual voltage is less than 85V for a short time, wait for the power system to restore itself to the normal voltage range.
		3. If the actual voltage is less than 85V for a long time, please contact the local power supply department
		4. If the actual voltage of the electrical system in your home is over 85V, please contact us;
Over Current	AC input current is too high	1.Cut off the power of the charger's power distribution box right away
		2.Check the charging plug for foreign objects and the car's on-board charger for abnormalities
		3.After troubleshooting the above problems, reconnect the power supply, if the fault still exists, please contact us
Over TEMP	Charger internal temperature greater than 85°C	1.Check that there is no other heat generating equipment or devices next to the charging station and make sure that the ambient temperature is below 50°C.
		2.If the problem cannot be solved, please contact us
Elec leakage	Leakage is greater than the following values: TypeA:(60Hz)AC20mA/ (50Hz)AC30mA TypeB: AC 30mA+DC 6mA	1.Cut off the power of the charger's power distribution box right away
		2.Check the charging plug for foreign objects and check the car for electrical leakage
		3. After troubleshooting the above problems, Reset leakage protector, reconnect the power supply, if the fault still exists, please contact us
Leakage self check	The sensor for detecting leakage is abnormal	1.Cut off the power of the charger's power distribution box right away
		2.Check whether the output cable of the charging station is broken or connected to ground
		3.After troubleshooting the above problems, reconnect the power supply, if the fault still exists, please contact us
PE Fault	Poor grounding or incorrect wiring	1.Cut off the power of the charger's power distribution box right away.
		2.Check if the charging station is grounded properly.
		3.After troubleshooting the above problems, reconnect the power supply, if the fault still exists, please contact us
Err:cp	Charging plug CC/CP connection abnormality	1.Check if the wiring of the charging plug is correct
		2. After troubleshooting the above problems, if the fault still exists, please contact us
Err:Reset	Reset button is pressed	1.Check if the red button on the right is pressed, if it is pressed, rotate it back to reset.
		2.After troubleshooting the above problems, if the fault still exists, please contact us
Err:LoadBalance	standby current+charging current<8A	1.Check if the sum of the standby current and charging current is less than 8A. If that's the case, reduce the current of your home appliances.
		2.After troubleshooting the above problems, if the fault still exists, please contact us

Charging Status and Indicator Light

Charging Status	Green Light	Blue Light	Red Light	Description
Ready	Ever-bright	/	/	Power-up for self-test or reset
Connect	Flashing	/	/	Detection point 1 voltage is 9 ± 0.8 V.
Charging	/	Breathing	/	Detection point 1 voltage is 6 ± 0.8 V,relay closed
Finish	/	Ever-bright	/	Charging finished
Err:CP	/	/	Flash 1 time(0.5S)	Detection point 1 voltage is 9.8V<U<11.2V; 6.8V<U<8.2V; 12.8V<U or U<5.2V; relay opened
Under Voltage	/	/	Flash 2 time(0.5S)	Single-phase: voltage <85V , Three-phase: <304V
Over Voltage	/	/	Flash 3 time(0.5S)	Single-phase: voltage > 264V, Three-phase: > 457V
Elec Leakage	/	/	Flash 4 time(0.5S)	Relay is opened, it will be closed if re-powered after troubleshooting,
Over Current	/	/	Flash 5 time(0.5S)	The line current keep at Ie+2<I≦Ie+4 for 5 seconds, the relay is opened, then restarted automatically after 10 seconds. It will permanently disconnect after three repetitions. At I> Ie+4, the relay is disconnected and the charging is finished.
Over Temp	/	/	Flash 6 time(0.5S)	Temperature > 85°C, the relay is opened. When the temperature is < 65 °C, charging restarts.
Err:Reset	/	/	Flash 7 time(0.5S)	Emergency stop button is pressed, the relay is opened, and it is allowed to close only after the fault is solved
Err:LoadBal-ance	/	/	Flash 9 time(0.5S)	standby current<8A

APP Download QR Code

Customer Service Team

E-mail: tina@feyree.com

Warranty

Two-Year Warranty

feyree offers two-year warranty to customers who make purchased original feyree product.

Lifetime Technical Support

In case of any product-related issues, we encourage you to reach out to us, providing pictures and videos for further assistance.

Exclusions

The warranty does not cover:

- Any product damage resulting from failure to follow the recommended guidelines.
- Damage caused by unauthorized disassembly of the machine or seeking maintenance from a non-designated service center.
- Purchased not original feyree products.
- Any modifications or do-it-yourself alterations carried out without guidance from a licensed electrician.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1)This device may not cause harmful interference; (2) this device must accept any interference received,including interference that may cause undesired operation.

Note:This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.This equipment generates and uses can radiate radio frequency energy, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following
measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

Note:The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance.such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meetgeneral RF exposure requirement.
To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20cm between the radiator and your body,and fully supported by the operating and installation configurations of the transmitter and its antennas.



www. feyree. com

Made in China