


# ASSEMBLY INSTRUCTIONS

## CORNER SOFA SET



WF320194AAE

WF320195AAE

WF320196AAE

WF320194AAE





Ⓐ x1

Ⓑ x1

Ⓒ x2

Ⓓ x2

Ⓔ x8





WF320195AAE

Ⓕ x2

Ⓒ x2

Ⓓ x2



Ⓔ x8



WF320196AAE


Ⓖ x2

Ⓒ x2




Part List:

A x1




B x1




F x2




G x2



C x6




D x4




E x16



# STEP1




# STEP2




# STEP3

x2




# STEP4


x2



STEP5




STEP6



STEP7

x2



STEP8

x2

