



Compass Wiring Diagram

F722 PRO




F722 MINI



10V Electronic Switch

1. The Flight Controller Connects To The BF Configurator And Switches To The Mode Screen At.



2. Scroll down to find USER1, select Add Range, toggle the rocker switch the remote wants to set, and after that the motor saves. Activate this USER1

