

# The Fesley Flute

The Left Hand	Th	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○									
	In	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●									
	Mi	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●									
	Ri	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●									
	Li									7										7																				
The Right Hand	In	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●										
	Mi	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●										
	Ri	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●										
	Li	0	1	2	2	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3									
Finger Method Of Tones	B	1	♯1	2	♯2	3	4	♯4	5	♯5	6	♯6	7	1	♯1	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2
	♭B	♯1	2	♯2	3	4	♯4	5	♯5	6	♯6	7	1	♯1	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2
	A	2	♯2	3	4	♯4	5	♯5	6	♯6	7	1	♯1	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3
	♭A	♯2	3	4	♯4	5	♯5	6	♯6	7	1	♯1	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4
	G	3	4	♯4	5	♯5	6	♯6	7	1	♯1	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4
	♭G	4	♯4	5	♯5	6	♯6	7	1	♯1	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5
	F	♯4	5	♯5	6	♯6	7	1	♯1	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5
	E	5	♯5	6	♯6	7	1	♯1	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6
	♭E	♯5	6	♯6	7	1	♯1	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6	♯6
	D	6	♯6	7	1	♯1	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6	♯6	7
	♭D	♯6	7	1	♯1	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i
	C	7	1	♯1	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i	2	♯2	3	4	♯4	5	♯5	6	♯6	7	i	♯i

Note: ●---Means "press", ○---Indicates that the thumb presses the down key, ⊙---Indicates that the thumb presses the up key.



**Fesley** is the name you can trust for high-quality, affordable musical instruments. Born from our passion to make the joy of music accessible to beginners, we proudly present our 16-hole closed flute. Fesley's unwavering commitment to craftsmanship and value ensures that every aspiring musician can discover their potential without breaking the bank. Join the Fesley family today and let your musical journey begin!

The finger table is designed according to the 17-hole flute in which "o" represents the E key, and the flute shown here is a 16-hole closed flute without the E key. "1" to "7" is shown in the figure.

# FESLEY

TO LEAD A NEW COOL

To connect directly with our Support team, please email [support@fesleymusic.com](mailto:support@fesleymusic.com)

