


AMSOF23-PK1
AMSOF23-PK2
AMSOF23-PK3
AMSOF23-PK4



IMPORTANT!

Product ships in
MULTIPLE
PACKAGES.
PACKAGES may
arrive separately.



IMPORTANT INFORMATION

Package Delivery & Unpacking



Product ships in multiple PACKAGES. PACKAGES may arrive separately. Please wait patiently. If you have any questions, feel free to contact us.



During unpacking, avoid using sharp objects that may scratch or damage the fabric surface.

Preparation Before Assembly



Notice

- Please read the entire instruction manual before beginning installation. If this manual does not match your installation, please contact us.
- Before starting assembly, verify all parts are included and undamaged. Do not use damaged or defective parts. If you require replacement parts, please email customer service.
- Make sure you have enough space to lay the parts out before assembling.



Caution

To avoid scratches, assemble this product on unfolded cardboard or a soft surface.

Safety Information



Warning

- Risk of electric shock — Always unplug the unit before cleaning or servicing.
- Do not use if the cord or plug is damaged.





- Use a vacuum cleaner to remove any loose debris.
- Clean using mild detergent with a damp cloth.
- Periodically inspect screw tightness after assembly. If necessary, retighten to ensure structural integrity.

Common Sofa Configurations




Note: This manual provides assembly instructions for several modules. If you have any questions, please email customer service.




...


AMSOF23-PK1



1 x 1



2 x 1



A x 4



D x 1




E x 1




F x 1


AMSOF23-PK2




6 x 1




8 x 1



9 x 1



A x 2



B x 2



M6 x 18mm


C x 6




5/32" (4mm)

G x 1


AMSOF23-PK3




3 x 1




4 x 1



5 x 1




9 x 1




A x 4




AMSOF23-PK4





7 x 2




! **Note:** Take out the sofa legs, power adapter, power cord, and connection cable from the armrest.




2






3





! Note: Zip the zippers sequentially following the numbers: ①, ②, ③.




5





6




7






2x




Tip: Adjust the footrest and the base frame as needed, then align the pins with the frame holes and insert fully to secure.





Tip: If it is difficult to insert, slightly push the base frame inward.



8








Installation Guide





Lift one sofa section, align its male latches with female latches of the adjacent section, and insert until the two sections lock securely in place. Attach the remaining parts one by one.


Note: Distinguish between male and female latches.





! Note: Zip up all zippers.





Headrest Adjustment



Tip: Hold the headrest with both hands when adjusting the angle to ensure both sides lock evenly. To return upright, press the headrest all the way down, then release it.

