

GREEN AND GOLD WASHING MACHINE (WCF30)











Assembly Instruction

*Please follow this instruction to avoid assembly errors.
*For customer service, please contact E-mail: shop@robud.com




⚠ WARNING:

CHOKING HAZARD-Small parts. Not suitable for children under 3 years.
Toys intended to be assembled by an adult. Children should use the product under adult's guidance.
After opening the package, please keep the packaging items such as plastic film or bags away from babies and children to avoid danger of suffocation.
Please keep the product away from fire, substances flammable and humid environments to prevent damage.
Please keep the product away from water, and don't put liquid in the toy sets.
Please clean the product with dry soft cloth, don't clean this product with chemical cleaners: alcohol, ammonia water, glass cleaner, etc.
⚠ is not a toy! Please keep the tool for future use and store it where children cannot access it.
The instruction must be retained since it contains important information.




				
x1	x1	x1	x1	x1
				
x1	x1	x1	x1	x1
				
x2	x1	x2	x2	x4
	 M3x12	 M3x28	 M4x8	 M4x30
x1	x2	x2	x4	x8
 M4x20	 M5x30			
x4	x16	x2	x1	x4


Accessories

				
x1	x1	x1	x1	x1


1  M4x30 8 pcs  2 pcs




2  M3x12 2 pcs  M3x28 2 pcs  M4x8 4 pcs  M5x30 6 pcs




3 22 M5x30 1 pcs




4 22 M5x30 1 pcs




5 22 M5x30 2 pcs




6




7 22 M5x30 1 pcs




8




9 21 M4x20 2 pcs




10 21 M4x20 2 pcs 22 M5x30 5 pcs



11



12



13

