

Caramel Washing Machine (WCF55)

Assembly Instruction





















*Please follow this instruction to avoid assembly errors.
*For customer service, please contact *E-mail: shop@robud.com*

⚠ WARNING:

- CHOKING HAZARD-Small parts. Not suitable for children under 3 years.
- Toys intended to be assembled by an adult. Children should use the product under adult's guidance.
- After opening the package,please keep the packaging items such as plastic film or bags away from babies and children to avoid danger of suffocation.
- STRANGULATION HAZARD-Long cord.
- Please keep the product away from fire, substances flammable and humid environments to prevent damage.
- 35** is not a toy! Please keep the tool for future use and store it where children cannot access it.













MAINTENANCE:


- Please clean the product with dry soft cloth,don't clean this product with chemical cleaners: alcohol, ammonia water, glass cleaner, etc.
- Please keep the product away from fire, substances flammable and humid environments to prevent damage.
- Please keep the product away from water,and don't put liquid in the toy sets.

Product Parts&Hardware				
				
x1	x1	x1	x1	x1
				
x1	x1	x1	x2	x1
				
x1	x1	x1	x1	x6
				
x2	x2	x1	x4	x1




98.1WCF55.150

				
x1	x1	x1	x1	x1
				
x2	x4	x12	x2	x24
				
x8	x1	x2	x4	x1




3




Notice:

Press 34 firmly against the tabletop with no gap then tighten the screws.


4




9




10




5




6




11




12




7



8




13





Notice:

First align the gear, then tighten the screws.



14





15



16




17





Notice:

Lower the tabletop into place, make sure the holes are aligned then secure it with screws.



18




19




20




21




22

33   1PCS



23

31  4PCS
M4x30mm



24

