

Caramel Dishwasher

(WCF56)



98.1WCF56.150

Assembly Instruction

*Please follow this instruction to avoid assembly errors.
*For customer service, please contact **E-mail: shop@robud.com**












⚠️ WARNING:








- CHOKING HAZARD-Small parts. Not suitable for children under 3 years.
- Toys intended to be assembled by an adult. Children should use the product under adult's guidance.
- After opening the package,please keep the packaging items such as plastic film or bags away from babies and children to avoid danger of suffocation.
- STRANGULATION HAZARD-Long cord.
- Please keep the product away from fire, substances flammable and humid environments to prevent damage.
- 29** is not a toy! Please keep the tool for future use and store it where children cannot access it.

MAINTENANCE:


- Please clean the product with dry soft cloth,don't clean this product with chemical cleaners: alcohol, ammonia water, glass cleaner, etc.
- Please keep the product away from fire, substances flammable and humid environments to prevent damage.
- Please keep the product away from water,and don't put liquid in the toy sets.

Product Parts


				
x1	x1	x1	x1	x1
				
x1	x1	x1	x1	x1
				
x2	x1	x1	x1	x1
				
x1	x1	x2	x2	x2

				
x1	x4	x2	x4	x2
				
x2	x12	x4	x1	x1

1




2




⚠️ Notice:
Pay attention to the direction of the magnet.


3



4




5

**Notice:**


First align the wooden dowel, then tighten the screw.

6


**Notice:**

First align the wooden dowel, then tighten the screw.

11




12


**Notice:**

Lower the tabletop into place, make sure the holes are aligned then secure it with screws.

7




8


**Notice:**

Press 28 firmly against the tabletop with no gap then tighten the screws.

13




14


**Notice:**

Place the knot into the groove of the wooden block as shown.


9



10



15



16

