

Assembly Instruction

*Please follow this instruction to avoid assembly errors.
*For customer service, please contact **E-mail: shop@robud.com**

 WARNING:

- CHOKING HAZARD-Small parts. Not suitable for children under 3 years.
- Toys intended to be assembled by an adult. Children should use the product under adult's guidance.
- After opening the package, please keep the packaging items such as plastic film or bags away from babies and children to avoid danger of suffocation.







MAINTENANCE:


- Please clean the product with dry soft cloth,don't clean this product with chemical cleaners: alcohol, ammonia water, glass cleaner, etc.
- Please keep the product away from fire, substances flammable and humid environments to prevent damage.
- Please keep the product away from water,and don't put liquid in the toy sets.




98.1WCF69.150

Product Parts


				
x1	x4	x1	x1	x1
				
x2	x1	x1	x1	x1
				
x1	x1	x2	x1	x1
				
x1		x24		




5




6




9




10



7



8



11



12

