

Assembly Instruction




*Please follow this instruction to avoid assembly errors.
*For customer service, please contact **E-mail: shop@robud.com**

 WARNING:



- Toys intended to be assembled by an adult. Children should use the product under adult's guidance.
- After opening the package please keep the packaging items such as plastic film or bags away from babies and children to avoid danger of suffocation.
- Do not use close to the ear! Misuse may cause damage to hearing.
- Please keep the product away from fire, substances flammable and humid environments to prevent damage.
- Please keep the product away from water, and don't put liquid in the toy sets.
- Please clean the product with dry soft cloth, don't clean this product with chemical cleaners: alcohol, ammonia water, glass cleaner, etc.
- The instruction must be retained since it contains important information








Product Parts

		
x1	x1	x1


Hardware and Accessories

 M4x35mm		
x9	x9	x1


Suitable Bricks/Materials

					
Concrete	Natural dense stone	Solid brick	Sand brick	Lightweight concrete	Concrete hollow brick

It can be placed on the carpet for play.



It can be installed on the wall for play.




Installation position on the wall:

Take a height of 80cm as an example as shown in the picture.


Notice:

It is recommended to install according to the child's sight line ;
it can also be installed according to the height you need.




Other installation height references:



1.Higher than the line of sight.




2.Near the skirting line



Instruction of anti-tip assembly

Use the electric drill to drill holes on marks.
The punching depth should be longer than the part to be inserted(the expandable tube ⑤)
Place the expandable tubes ⑤ into the drilled holes.
Finally,screw ④ into two hole for the expandable tubes.



- Acceptance criteria:**
1. After the screws are tightened, the back board is flush with the wall.
 2. Pull the edge with both hands, and there is no movement or abnormal noise of the back board.
 3. Ensure that the busy board is installed correctly and firmly, and check regularly to ensure its stability.

- Tips:**
1. Children need to use it under the supervision of parents.
 2. It is forbidden to hang heavy objects on the protruding parts of the product.
 3. Check the screws regularly (recommended 1 - 2 weeks).
 4. The expansion hose is a one-time consumable and is only for the first installation. Spare parts are not included. If reinstallation is needed, please purchase a new expansion hose by yourself.