LR 210

HVO®

STANDING LATERAL RAISE MACHINE

USER MANUAL

SAFETY PRECAUTIONS 01-03

INSTALLATION STEPS 07-14

WARRANTY 21

SICHERHEITSVORKEHRUNGEN 23-25

MONTAGESCHRITTE 29-36

GARANTIE 43

Thank you for purchasing this product.

Before using this product, please read the instructions in this manual carefully, paying particular attention to safety precautions. Keep this owner's manual for future reference.

Note: Any discrepancies between the product's functionality in the market and the manual's description are due to normal product updates, for which our company will not provide individual notifications. Our company reserves the right to modify and interpret the product design. During transportation, rough handling by logistics may cause product damage. We appreciate your understanding and are ready to promptly address any issues with your product.

CONTENTS

SAFETY PRECAUTIONS ---------- 01-03

PACKAGE CONTAINS ---------- 04-05

MODEL AND PART DESCRIPTION ---------- 06

INSTALLATION STEPS ---------- 07-14

USAGE PRECAUTIONS ---------- 15-20

WARRANTY ---------- 21

INHALTSVERZEICHNIS

SICHERHEITSVORKEHRUNGEN ---------- 23-25

VERPACKUNGSINHALT ---------- 26-27

MODELL-UND TEILEBESCHREIBUNG ---------- 28

MONTAGESCHRITTE ---------- 29-36

VORSICHTSMASSNAHMEN BEI DER BENUTZUNG ---------- 37-42

GARANTIE ---------- 43

Product Warranty

To register your product, please forward your order number to our dedicated after-sales email address at **service@hvofitness.com** By activating your warranty, you will not only receive the standard 6-month warranty but also an additional 180 days of coverage, giving you a total of one year of peace of mind for your purchase.

Return Policy

If you encounter any issues with your product, you may return new and unopened items within 30 days of delivery for a full refund or replacement. The initial return period is within 7 days of receiving the goods. Upon receipt of the product, please inspect the contents of the box to ensure it is in good condition. It is essential to retain the original packaging, such as cartons, for use during repairs.

Product Warranty

Um Ihr Produkt zu registrieren, senden Sie bitte Ihre Bestellnummer an unsere spezielle Kundendienst-E-Mail-Adresse unter **service@hvofitness.com** Wenn Sie Ihre Garantie aktivieren, erhalten Sie nicht nur die standardmäßige 6-monatige Garantie, sondern auch eine zusätzliche 180-Tage-Garantie, so dass Sie insgesamt ein Jahr lang Ruhe vor dem Kauf haben.

Return Policy

Sollten Sie Probleme mit Ihrem Produkt haben, können Sie neue und ungeöffnete Artikel innerhalb von 30 Tagen nach der Lieferung zurücksenden und erhalten eine volle Rücker-stattung oder Ersatz. Die ursprüngliche Rückgabefrist beträgt 7 Tage nach Erhalt der Ware. Bitte überprüfen Sie bei Erhalt des Produkts den Inhalt des Kartons, um sicherzustellen, dass er in gutem Zustand ist. Bewahren Sie unbedingt die Originalverpackung, wie z.B. Kartons, für die Verwendung bei Reparaturen auf.

HVO

Harness Vitality with HVO

Thank you for your purchase of the HVO Product.

Brand Story

HVO promotes a healthy and active lifestyle, reflected in our brand name, which stands for Health, Vitality, and Optimism. At HVO, we believe fitness is personal. That's why we're redefining what it means to train by bringing the power of professional-grade strength training right into your space. No waiting, no sharing, no compromises—just you, your goals, and the equipment designed to help you crush them.We specialize in unleashing the potential of anaerobic strength training, helping you activate every muscle, push every limit, and achieve results faster. Whether you're sculpting your physique, building raw power, or simply becoming the strongest version of yourself, HVO is your partner in progress.

Your Gym. Your Rules.
Welcome to the future of personal strength training. Welcome to HVO.

SAFETY PRECAUTIONS

Please read all instructions carefully before assembling and operating this product. This unit is designed with safety as a top priority. It is important to retain this owner's manual, avoid removing any safety labels from the machine, and keep the original purchase receipt for future reference.

⚠ Important Safety Instructions

Please thoroughly read and understand all warnings on this machine. Carefully review and comprehend the assembly instructions.

⚠ Warning

This icon indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury.

⚠ Attention

This icon signifies that failure to follow the instructions may result in injury and damage to the equipment.

⚠ Warning

❶ This product is designed for home use only. Please do not use it in environments frequented by the general public, such as schools or gyms.

❷ Users should exercise caution under the following conditions:

- Individuals undergoing medical treatment or feeling unwell.
- Pregnant individuals, those suspected of being pregnant, or those menstruating.
- Individuals with heart or respiratory conditions requiring rest.
- Individuals with implantable medical devices such as pacemakers.
- Individuals diagnosed by a physician as unfit for exercise.
- Individuals feeling unwell or fatigued.

❸ The following individuals should consult a doctor before use:

- Individuals with sensory impairments.
- Individuals with circulatory or vascular disorders.
- Individuals with bone issues.
- Individuals with visceral diseases such as hepatitis or gastritis.
- Individuals with malignant tumors.
- Individuals with rheumatism, ventilation, or arthritis.
- Individuals with spinal deformities or curvature.
- Individuals with lumbar disc herniation or spondylolysis.
- Individuals experiencing numbness in the feet, waist, neck, or hands.
- Individuals with varicose veins, high blood pressure, or thrombosis.
- Individuals using the product for rehabilitation purposes.

❹ This equipment is not intended for use by individuals below elementary school age. Children must not be allowed on or near this machine.

❺ Only one person should use the equipment at a time.

Product Assembly

1. Please take the time to read all assembly instructions before attempting to assemble your product.
2. When assembling or using this product, please pay attention to safety and prevent your fingers from being caught by moving parts.
3. When assembling, to avoid damaging the floor or surrounding furniture, please place it on a soft object such as a protective pad.
4. Due to the risk of injury, for safety reasons, please wear gloves and ensure that more than two people assemble the device together.
5. Failure to assemble and use according to this manual may result in serious accidents, so please adhere to the guidelines.

⚠ Attention

1. Please ensure that all parts are complete before assembly. If any parts are missing, please contact Customer Service.
2. Ensure that you assemble and set up the product in a spacious area, taking care not to damage surrounding furniture and floors.
3. When assembling, be careful not to injure yourself with the tools. Exercise caution when using them.
4. Inspect your product to ensure that all fasteners are tight and components are properly assembled. Review all warnings attached to the machine.

Product Use

1. Please confirm that the area is safe, spacious, and free of obstacles before using the equipment.
2. Ensure your equipment is correctly assembled before use. Verify that all screws, nuts, bolts, weight stacks, pins, and adjustable parts are properly installed and securely fixed.
3. Do not operate this equipment if it is damaged, shows signs of wear, or functions abnormally.
4. Stretch and warm up before use. Failure to stretch may result in injury.
5. Always wear proper exercise attire when using the equipment. Be cautious when getting on or off the unit.
6. If you feel faint, light-headed, dizzy, or experience pain or discomfort while using the equipment, stop exercising immediately.
7. Keep children and pets away from the equipment at all times.
8. Keep loose clothing, jewelry, limbs, and long hair away from moving parts.
9. Never attempt to exercise with more resistance than you are physically able to handle.

10. Wait at least 2 hours after eating before using the exercise equipment. Stop exercising immediately if you feel nauseous.
11. Never exercise after consuming alcohol.
12. Do not use this product as a chair, ladder, or for any other improper purposes.
13. Do not use this product as a toy. Ensure that all users read and understand the instructions and warnings before use.

⚠ Attention

1. This product is designed for indoor use only and should not be used outdoors. Ensure it is placed on a flat, stable, and horizontal surface.
2. Do not place it in areas where moisture is heavy or splashed by water droplets, as it may cause rust or malfunction.

Product Maintenance

1. After each session, clean the training device with a clean, damp cloth to remove sweat and moisture. Do not use solvents. Ensure all surfaces are thoroughly dried after cleaning.
2. For upholstery, use a mild detergent or spray cleaner. For a deeper clean, wipe all surfaces with an ammonia-based cleanser. This is recommended at least once a week for frequently used equipment. Ensure the product is completely dry afterwards.
3. Check all screws, nuts, bolts, and adjustable parts at least once a month. Retighten as necessary to maintain the structural integrity of the equipment.
4. Pay special attention to components most susceptible to wear, including cables, pulleys, weight stack guides, and adjustment pins. Regularly inspect these parts and all connection points for signs of wear, fraying, or fatigue.
5. Inspect the frame periodically for any signs of cracking, permanent bending, or surface damage. Repair scratches or chips on metal surfaces immediately using touch-up paint to prevent rust.
6. If any damage, excessive wear, or deformation is detected, stop using the equipment immediately. Replace defective components and do not use the equipment until it has been fully repaired.

Note: The warranty does not cover damage resulting from improper maintenance.

Product Storage

1. Store the product in a stable and flat location, away from areas where it may be a tripping hazard or could fall and cause injury.
2. Keep the equipment out of reach of children. Ensure children cannot climb on or be near the product.
3. Store the product away from direct sunlight, high temperatures, and moisture to prevent damage and corrosion.


PACKAGE CONTAINS

Please carefully check whether the contents of the package are complete and intact. If there is anything missing or damaged, please contact the HVO customer service at


service@hvofitness.com

Important Note:
Do not overtighten the screws during assembly for better adjustment !
Only tighten them once everything is completely installed !


Part List 1




1. Rear Foot Tube




2. Front Foot Tube




3. Connector Tube




4. Main Frame




5. Rear Connector Tube




6. Foot Plate




7. Short Handle Frame x2
(Pre-installed)




8. Long Handle x2
(Pre-installed)




9. Long Handle Frame x2
(Pre-installed)




10. Short Handle x2




11. Weight Plate Holder x4




12. Arm Support Shaft



13. Back Cushion




14. Seat Cushion




15. End Cap x4
(Pre-installed)


PACKAGE CONTAINS



16 .13cm Metal Plate x2




17. 11cm Metal Plate x4




18. Seat Cushion Support


Part List 2




A. Hexagonal Bolt M10*60
x8pcs




B. Hexagonal Bolt M10*70
x8pcs




C. Hexagonal Bolt M10*95
x2pcs




D. Flat Washer M10
x40pcs




E. Lock Nut M10
x22pcs




F. Carriage Bolt M10*70
x4pcs




G. Hex Socket Screw M8*25
x2pcs



H. Hex Socket Screw M8*70
x2pcs



I. Flat Washer M8
x4pcs



J. Flat Washer M20
x4pcs

MODEL AND PART DESCRIPTION


Important Note:
Do not overtighten the screws during assembly for better adjustment !
Only tighten them once everything is completely installed !

HVO FITNESS

LEARN MORE ON OUR YOUTUBE CHANNEL.
SCAN TO VISIT.

SCAN TO CONNECT WITH THE HVO SUPPORT TEAM


SCAN ME




INSTALLATION STEP 1

1. Assemble the Base

1. Attach the rear connector tube (No. 5) and connector tube (No. 3) to the rear foot tube (No. 1).
2. Attach the foot plate (No. 6) and front foot tube (No. 2) to the connector tube (No. 3), with the front foot tube (No. 2) between them.



Note: The front foot tube (NO.2) is shorter than the rear foot tube (NO.1)




Important Note:
Do not overtighten the screws during assembly for better adjustment !
Only tighten them once everything is completely installed !


INSTALLATION STEP 2

2. Assemble the Main Frame

1. Attach the main frame (No. 4) to the rear connector tube (No. 5).
2. Attach the main frame (No. 4) to the connector tube (No. 3) and secure with the 13 cm plate (No. 16).



(4)



(16)



(B) x2




(D) x6



(E) x4




(F) x2




INSTALLATION STEP 3

3. Install the Arm Support Shaft and Back Cushion

1. Attach the back cushion (No. 13) to the main frame (No. 4).
2. Connect the arm support shaft (No. 12) to the rear connector tube (No. 5), and secure it with the 13 cm reinforcement plate (No. 16).







INSTALLATION STEP 4

4. Install the Short Handle

Attach the two short handles (No. 10) to each long handle frame (No. 9).



(9) x2



(10) x2



(C) x2




(D) x4



(E) x2




(J) x4




INSTALLATION STEP 5

5. Install the Weight Plate Holders

1. Attach the weight plate holder (No. 11) to the short handle frame (No. 7), and secure it with the 11 cm plate (No. 17).
2. Attach the weight plate holder (No. 11) to the long handle frame (No. 9), and secure it with the 11 cm plate (No. 17).



(11) x4



(17) x4




(A) x8




(D) x16



(E) x8




INSTALLATION STEP 5




INSTALLATION STEP 6

6. Install the Seat Cushion


1. Assemble the seat cushion support (No.18) and seat cushion (No.14)
2. Mount the assembled seat cushion unit onto the main frame (No.4).



(14)




(18)




(G) x2




(I) x2







FINISH

After completing all steps, tighten all screws to ensure the machine is stable before use and exercise.









USAGE PRECAUTIONS

Note: To use a 30 mm (1 inch) diameter weight plate, disassemble parts (11-A) using an L-shaped Allen key as shown in the picture.




USAGE PRECAUTIONS

Standing Lateral Raise (Rear)




Start




Finish

Side Raise (Rear)




Start




Finish

Unilateral Front Raise (Rear)



Start



Finish

USAGE PRECAUTIONS

Note:When performing the Bent Over Lateral Raise or Seated Bent Over Lateral Raise, do not load weight plates on the upper.

Bent Over Lateral Raise (Front)



Start



Finish

Seated Bent Over Lateral Raise (Front)



Start



Finish

DEAR SIR/MADAM.

Thanks for your order of product at HVO ! We hope you are satisfied with our products and service.

Share Your HVO Fitness Journey & Get Rewarded!
We'd love to see your HVO exercise machine in action!
Share your photos or videos of:

Favorite workout routines
Creative ways to use your equipment



How to participate:
Post to YouTube / Instagram / Facebook / Reddit

Tag us:
Facebook: @HVO
Instagram: @HVO Fitness
YouTube: @HVO-Fitness
Reddit: #HVOFitness / #HVOFitnessCommunity

Scan the Massager QR Code to Contact **HVO Fitness**, or Email Your Order # + Photo/Video Link/Screenshots to: **service@hvofitness.com**
Share your thoughts with videos and get rewarded with **$30-$50** via PayPal!

Your insights could make a difference!

Scan the QR code to contact **HVO Fitness**, or email your order number to **service@hvofitness.com** to register your product. Once you activate your warranty, you will receive an additional 180 days of coverage on top of the standard warranty, giving you a full year of peace of mind for your purchase.

Youtube: HVO **HVO Fitness** **Instagram: HVO**



Messenger QR Code Not Working?
Search **HVO Fitness** on Facebook and click Send Message to contact us.

NOTICE:

If you are not satisfied with the Product, please reach out to us and we will reply you within 24 hours. We strive to provide the best possible service to our custom ers. Your satisfaction is important.

USAGE PRECAUTIONS

1. Training Plan & Tips

Training Frequency

Experts recommend doing weight training 3 to 4 days a week. You will of course reach your training target quicker if you train more regularly. Make sure that you allow for sufficient breaks in your training plan to give your body time to recover and regenerate. After each training session you should take at least a one-day break. The rule of “less is often more” even applies to fitness and weight training.

Trainings Records

To optimise your training and make it as effective as possible you should work out a training plan, before you start training, which you either write down or create a table for in your computer. Here you should make a record of training session and how you feel during the training session.

Here is a recommende weekly plan.

CALENDAR WEEK:_____ YEAR: 20____						
Date	**Exercise**	**Sequence 1**	**Sequence 2**	**Sequence 3**	**Sequence 4**	**Comments**
		___ lb ___Rep	___ lb ___Rep	___ lb ___Rep	___ lb ___Rep	
		___ lb ___Rep	___ lb ___Rep	___ lb ___Rep	___ lb ___Rep	
		___ lb ___Rep	___ lb ___Rep	___ lb ___Rep	___ lb ___Rep	
		___ lb ___Rep	___ lb ___Rep	___ lb ___Rep	___ lb ___Rep	
		___ lb ___Rep	___ lb ___Rep	___ lb ___Rep	___ lb ___Rep	
		___ lb ___Rep	___ lb ___Rep	___ lb ___Rep	___ lb ___Rep	
		___ lb ___Rep	___ lb ___Rep	___ lb ___Rep	___ lb ___Rep	

Explanation of Terms:

Weight training exercises are usually made up of three or four training sequences. Each training sequence is normally made up of 10 to 12 repetitions of an exercise. At the end of each training sequence you should have a 1 to 2-minute recovery break.Normally the weights used in training are increased from sequence to sequence.

A Training Session could be as follows:

1. Training Sequence	Training Weight 40 lb	10 Repetitions Break	1 Minute
2. Training Sequence	Training Weight 50 lb	10 Repetitions Break	1 Minute
3. Training Sequence	Training Weight 60 lb	10 Repetitions Break	1 Minute
4. Training Sequence	Training Weight 70 lb	10 Repetitions Break	1 Minute

2. Training Recommendations

Preparation Before Training
Before you start training make sure that not only your training device is in perfect condition, your body must also be pre-pared for training. Therefore, if you have not done any endurance training for some time, you should consult your GP and undergo a fitness check-up. Also discuss your training target; they will certainly be able to give you valuable advice and information. This applies to people who are over 35, have problems with overweight, heart or circulatory system problems.

Training Plan
Essential to effective, target orientated, and motivating training is to have a forward-looking trainings plan. Plan your fitness training as an integral part of your daily routine. If you don’t have a fixed plan, training can easily interfere with regular commitments or continually be put off to another unspecified time.

Warm-Up Before Training
Warm-up on your training device for 3-5 minutes at minimum resistance. This will best prepare your body for the up-coming exertion in training.

Cool-Down After Training
Do not just get off your training device immediately the training session is finished. Like with the warm-up stage you should continue for 3-5 minutes at minimum resistance to cool down. After training you should stretch your muscles thoroughly.

Training Safety and Equipment Handling

1. Before starting your training session, ensure that all weight stacks, external counterweights, and adjustable parts are correctly installed and securely fixed.
2. Only add or remove weight plates when the equipment is stationary and on a stable surface.
3. Use two hands and a stable stance when handling weight plates. Avoid overreaching or sudden movements.
4. Make sure all weight plates are fully seated on their designated posts and secured with locking pins before beginning any exercise.
5. Keep fingers, hands, and other body parts clear of moving parts while installing or removing weights.
6. Never attempt to lift or remove weights that exceed your personal strength limits.
7. Regularly inspect the equipment for wear or damage, especially cables, pulleys, pins, and weight stack guides. If any issues are found, stop using the equipment immediately and contact Customer Service.

USAGE PRECAUTIONS



Front Thigh Muscles
Support yourself with your right hand against the wall or on your training device. Bend your knee and raise your left foot backwards so you can hold it with your left hand. Your knee should be pointing straight down to the floor. Pull your leg backwards until you feel a light pulling in your thigh muscles. Hold this position for 10 to 15 seconds. Let your foot go and stand it back on the floor. Repeat the exercisewith your right leg.



Inner Thigh Muscles
Sit on the floor. Pull the soles of your feet together in front of you raising your knees slightly. Grasp the upper sides of your feet and place your elbows on your thighs. Press your thighs down towards the floor with your arms until you feel a light pulling in your thigh muscles. Hold this position for 10 to 15 seconds. Make sure to keep your upper body straight throughout the exercise. Release the pressure from your thighs and slowly stretch out your legs to the front. Stand up slowly steadily.



Legs, Calves and Buttocks
Sit on the floor. Stretch out your right leg and bend your left leg to place the sole of your foot on your right thigh. Bend your top body over so you can stretch out your right hand to touch your right toes. Hold this position for 10 to 15 seconds. Let go of your toes and sit slowly and steadily up straight again. Repeat this exercise with your left leg.



Leg and Lower Back Muscles
Sit on the floor with your legs stretched out. Stretch forward with your hands and try to grasp the tips of your toes with both hands. Hold this position for 10 to 15 seconds. Let go of your toes and slowly and steadily sit back up straight again.

WARRANTY

To register your product, please email your order number and a screenshot of your order to **service@hvofitness.com** This step ensures that your product is properly registered in our system and activates your warranty.

❶ If you encounter any issues with your product, you can return new and unopened items within 30 days of delivery for a full refund or replacement.

❷ Register your product by sending your order number to our dedicated after-sales email address at **service@hvofitness.com** Upon warranty activation, you'll receive our standard 6-month warranty plus an additional 180 days, providing you with one year of coverage.

❸ During the warranty period, repairs (excluding consumables) are free, but customers are responsible for round-trip shipping costs.

❹ If your product's warranty expires, we'll provide and use stock accessories to the best of our ability to assist with repairs (charges may apply).

❺ Modifying the product yourself and attempting repairs will void the warranty.

❻ Due to distribution processes, the product may experience some friction and rough handling during shipping. We recommend keeping the packaging box in case a return is necessary. Without the packaging material, returns may not be possible.

Product Details	
Item name	HVO STANDING LATERAL RAISE MACHINE
Model	LR1201
Contains	HVO STANDING LATERAL RAISE MACHINE*1 + INSTRUCTIONS *1

HVO

Harness Vitality with HVO

Danke, dass Sie das HVO-Produkt gekauft haben.

Brand Story

HVO fördert einen gesunden und aktiven Lebensstil, was sich in unserem Markennamen widerspiegelt, der für Gesundheit, Vitalität und Optimismus steht. Bei HVO glauben wir, dass Fitness etwas Persönliches ist. Deshalb definieren wir das Training neu, indem wir die Kraft von professionellem Krafttraining direkt zu Ihnen nach Hause bringen. Kein Warten, kein Teilen, keine Kompromisse – nur Sie, Ihre Ziele und die Ausrüstung, die Ihnen hilft, sie zu erreichen. Wir spezialisieren uns darauf, das Potenzial des anaeroben Krafttrainings freizusetzen, um jeden Muskel zu aktivieren, jede Grenze zu überwinden und schneller Ergebnisse zu erzielen. Ob Sie Ihren Körper formen, pure Kraft aufbauen oder einfach die stärkste Version Ihrer selbst werden möchten – HVO ist Ihr Partner auf diesem Weg.

Ihr Fitnessraum. Ihre Regeln.
Willkommen in der Zukunft des persönlichen Krafttrainings. Willkommen bei HVO.

SICHERHEITSVORKEHRUNGEN

Bitte lesen Sie alle Anweisungen sorgfältig durch, bevor Sie dieses Produkt zusammenbauen und in Betrieb nehmen. Bei der Entwicklung dieses Geräts stand die Sicherheit an erster Stelle. Es ist wichtig, dass Sie dieses Benutzerhandbuch aufbewahren, keine Sicherheitsaufkleber von der Maschine entfernen und den Originalkaufbeleg für spätere Nachforschungen aufbewahren.

⚠ Wichtige Sicherheitshinweise

Bitte lesen und verstehen Sie alle Warnhinweise auf diesem Gerät sorgfältig. Lesen Sie die Montageanleitung sorgfältig durch und verstehen Sie sie.

⚠ Warnung

Dieses Symbol weist auf eine potenziell gefährliche Situation hin, die, wenn sie nicht vermieden wird, zum Tod oder zu schweren Verletzungen führen kann.

⚠ Achtung

Dieses Symbol bedeutet, dass die Nichtbeachtung der Anweisungen zu Verletzungen und Schäden am Gerät führen kann.

⚠ Warnung

1. Dieses Produkt ist nur für den Heimgebrauch bestimmt. Bitte verwenden Sie es nicht in Umgebungen, die von der Öffentlichkeit frequentiert werden, wie z.B. in Schulen oder Sporthallen.
2. Unter den folgenden Bedingungen sollten Sie Vorsicht walten lassen:
   - Personen, die sich in medizinischer Behandlung befinden oder sich unwohl fühlen.
   - Schwangere, Personen, bei denen der Verdacht auf eine Schwangerschaft besteht, oder Personen, die menstruieren.
   - Personen mit Herz- oder Atemwegserkrankungen, die Ruhe benötigen.
   - Personen mit implantierbaren medizinischen Geräten wie z.B. Herzschrittmachern.
   - Personen, die von einem Arzt als untauglich für Sport diagnostiziert wurden.
   - Personen, die sich unwohl oder müde fühlen.
3. Die folgenden Personen sollten vor der Einnahme einen Arzt konsultieren:
   - Individuen mit sensorischen Beeinträchtigungen.
   - Personen mit Durchblutungsstörungen oder Gefäßerkrankungen.
   - Personen mit Knochenproblemen.
   - Personen mit viszeralen Erkrankungen wie Hepatitis oder Gastritis.
   - Personen mit bösartigen Tumoren.
   - Personen mit Rheuma, Beatmung oder Arthritis.
   - Personen mit Wirbelsäulendeformationen oder -verkrümmungen.
   - Personen mit einem lumbalen Bandscheibenvorfall oder einer Spondylolyse.
   - Personen, die Taubheitsgefühle in den Füßen, der Taille, dem Nacken oder den Händen haben.
   - Personen mit Krampfadern, hohem Blutdruck oder Thrombose.
   - Personen, die das Produkt für Rehabilitationszwecke nutzen.
4. Dieses Gerät ist nicht für Personen unter dem Grundschulalter geeignet. Kinder dürfen nicht auf oder in der Nähe dieses Geräts sein.
5. Es sollte immer nur eine Person das Gerät benutzen.

Produktmontage

1. Bitte nehmen Sie sich die Zeit, alle Montageanweisungen zu lesen, bevor Sie versuchen, Ihr Produkt zusammenzubauen.
2. Achten Sie beim Zusammenbau oder der Verwendung dieses Produkts auf die Sicherheit und verhindern Sie, dass Ihre Finger von beweglichen Teilen eingeklemmt werden.
3. Um Beschädigungen des Fußbodens oder der umliegenden Möbel zu vermeiden, stellen Sie das Gerät beim Zusammenbau bitte auf einen weichen Gegenstand wie z.B. eine Schutzunterlage.
4. Wegen der Verletzungsgefahr sollten Sie aus Sicherheitsgründen Handschuhe tragen und sicherstellen, dass mehr als zwei Personen das Gerät zusammenbauen.
5. Wenn Sie das Gerät nicht gemäß dieser Anleitung zusammenbauen und verwenden, kann dies zu schweren Unfällen führen. Halten Sie sich daher bitte an die Richtlinien.

⚠ Achtung

1. Bitte vergewissern Sie sich vor dem Zusammenbau, dass alle Teile vollständig sind. Sollten Teile fehlen, wenden Sie sich bitte an den Kundendienst.
2. Achten Sie darauf, dass Sie das Produkt in einem geräumigen Bereich aufbauen und aufstellen und dabei darauf achten, dass Sie die umliegenden Möbel und Böden nicht beschädigen.
3. Achten Sie beim Zusammenbau darauf, dass Sie sich nicht mit den Werkzeugen verletzen. Seien Sie vorsichtig, wenn Sie sie verwenden.
4. Überprüfen Sie Ihr Produkt, um sicherzustellen, dass alle Befestigungen fest sitzen und die Komponenten richtig zusammengebaut sind. Überprüfen Sie alle am Gerät angebrachten Warnhinweise.

Produktverwendung

1. Bitte stellen Sie sicher, dass der Bereich sicher, geräumig und frei von Hindernissen ist, bevor Sie das Gerät benutzen.
2. Vergewissern Sie sich vor dem Gebrauch, dass das Gerät korrekt zusammengebaut ist. Prüfen Sie, ob alle Schrauben, Muttern, Bolzen, Gewichtsstapel, Stifte und verstellbaren Teile ordnungsgemäß montiert und sicher befestigt sind.
3. Benutzen Sie das Gerät nicht, wenn es beschädigt ist, Abnutzungserscheinungen zeigt oder nicht ordnungsgemäß funktioniert.
4. Dehnen Sie sich und wärmen Sie sich vor dem Training auf. Das Auslassen des Aufwärmens kann zu Verletzungen führen.
5. Tragen Sie stets geeignete Sportkleidung beim Training. Seien Sie vorsichtig beim Auf- und Absteigen vom Gerät.
6. Wenn Sie sich schwach, schwindelig, benommen oder unwohl fühlen, oder Schmerzen verspüren, brechen Sie das Training sofort ab.
7. Halten Sie Kinder und Haustiere jederzeit vom Gerät fern.
8. Halten Sie lose Kleidung, Schmuck, Gliedmaßen und langes Haar von allen beweglichen Teilen fern.
9. Versuchen Sie niemals, mit mehr Widerstand zu trainieren, als Sie körperlich bewältigen können.

⑩ Warten Sie mindestens 2 Stunden nach einer Mahlzeit, bevor Sie das Trainingsgerät benutzen. Brechen Sie das Training sofort ab, wenn Sie Übelkeit verspüren.

⑪ Trainieren Sie niemals nach Alkoholkonsum.

⑫ Verwenden Sie dieses Produkt nicht als Stuhl, Leiter oder für andere unsachgemäße Zwecke.

⑬ Verwenden Sie dieses Produkt nicht als Spielzeug. Stellen Sie sicher, dass alle Benutzer die Anweisungen und Warnhinweise vor der Benutzung gelesen und verstanden haben.

⚠ Achtung

❶ Dieses Produkt ist nur für den Innenbereich geeignet und sollte nicht im Freien verwendet werden. Stellen Sie sicher, dass es auf einer ebenen, stabilen und waagerechten Fläche steht.

❷ Platzieren Sie das Gerät nicht in Bereichen mit starker Feuchtigkeit oder direktem Wasserspritzkontakt, da dies Rost oder Fehlfunktionen verursachen kann.

Produktpflege

❶ Reinigen Sie das Trainingsgerät nach jeder Nutzung mit einem sauberen, feuchten Tuch, um Schweiß und Feuchtigkeit zu entfernen. Verwenden Sie keine Lösungsmittel. Stellen Sie sicher, dass alle Oberflächen nach der Reinigung vollständig getrocknet sind.

❷ Verwenden Sie für die Polsterung ein mildes Reinigungsmittel oder einen Sprühreiniger. Für eine gründlichere Reinigung wischen Sie alle Oberflächen mit einem ammoniakhaltigen Reinigungsmittel ab. Dies wird bei häufig genutzten Geräten mindestens einmal pro Woche empfohlen. Stellen Sie sicher, dass das Produkt anschließend vollständig trocken ist.

❸ Überprüfen Sie alle Schrauben, Muttern, Bolzen und verstellbaren Teile mindestens einmal im Monat. Ziehen Sie diese bei Bedarf nach, um die strukturelle Stabilität des Geräts zu gewährleisten.

❹ Achten Sie besonders auf Komponenten, die einem erhöhten Verschleiß unterliegen, wie z. B. Kabel, Rollen, Führungen des Gewichtsstapels und Verstellstifte. Überprüfen Sie diese Teile sowie alle Verbindungspunkte regelmäßig auf Anzeichen von Verschleiß, Ausfransungen oder Materialermüdung.

❺ Überprüfen Sie den Rahmen regelmäßig auf Anzeichen von Rissen, dauerhaften Verformungen oder Oberflächenschäden. Bessern Sie Kratzer oder Abplatzungen auf Metalloberflächen sofort mit Ausbesserungslack aus, um Rostbildung zu vermeiden.

❻ Wenn Schäden, übermäßiger Verschleiß oder Verformungen festgestellt werden, stellen Sie die Nutzung des Geräts sofort ein. Ersetzen Sie defekte Komponenten und verwenden Sie das Gerät erst wieder, wenn es vollständig repariert wurde.

Hinweis: Schäden, die durch unsachgemäße Wartung entstehen, sind von der Garantie ausgeschlossen.

Produktlagerung

❶ Lagern Sie das Gerät an einem stabilen und ebenen Ort, fern von Bereichen, in denen es eine Stolpergefahr darstellen oder herunterfallen und Verletzungen verursachen könnte.

❷ Halten Sie das Gerät außerhalb der Reichweite von Kindern. Stellen Sie sicher, dass Kinder nicht auf das Gerät klettern oder sich in dessen Nähe aufhalten können.


❸ Lagern Sie das Gerät fern von direkter Sonneneinstrahlung, hohen Temperaturen und Feuchtigkeit, um Beschädigungen und Korrosion zu vermeiden.

VERPACKUNGSINHALT


Bitte überprüfen Sie sorgfältig, ob der Inhalt des Pakets vollständig und unversehrt ist. Sollte etwas fehlen oder beschädigt sein, wenden Sie sich bitte an den HVO-Kundendienst unter **service@hvofitness.com**

Wichtiger Hinweis:
Ziehen Sie die Schrauben während der Montage nicht zu fest an, um eine bessere Einstellung zu erreichen !
Ziehen Sie sie erst fest, wenn alles vollständig montiert ist !


Teilelist 1




1. Hintere Fußrohr




2. Vordere Fußrohr




3. Verbindungsrohr




4. Hauptrahmen




5. Hinteres Verbindungsrohr




6. Fußplatte




7. Kurzgriff-Rahmen x2
(Pre-installed)




8. Langgriff x2
(Pre-installed)




9. Langgriff-Rahmen x2
(Pre-installed)




10. Kurzgriff x2




11. Hantelscheibenhalterung x4




12. Armstütz-Achse



13. Rückenkissen




14. Sitzkissen




15. Endkappe x4
(Pre-installed)


VERPACKUNGSINHALT



16 .13cm Verstärkungsblech
x2




17. 11cm Verstärkungsblech
x4




18. Verstellbarer
Sitzmechanismus


Teilelist 2




A. Sechseckige Schraube
M10*60 x8pcs




B. Sechseckige Schraube
M10*70 x8pcs




C. Sechseckige Schraube
M10*95 x2pcs




D. Unterlegscheibe
M10 x40pcs




E. Sicherungsmutte
M10 x22pcs




F. Schlossschraube
M10*70 x4pcs




G. Innensechskantschraube
M8*25 x2pcs



H. Innensechskantschraube
M8*70 x2pcs



I. Unterlegscheibe
M8 x4pcs



J. Unterlegscheibe
M20 x4pcs

MODELL-UND TEILEBESCHREIBUNG


Wichtiger Hinweis:
Ziehen Sie die Schrauben während der Montage nicht zu fest an, um eine bessere Einstellung zu erreichen!
Ziehen Sie sie erst fest, wenn alles vollständig montiert ist!

HVO FITNESS

MEHR VIDEO-ANLEITUNGEN AUF YOUTUBE.
EINFACH SCANNEN!

SCANNEN UND DAS HVO-SUPPORT-TEAM
KONTAKTIEREN


SCAN ME




MONTAGESCHRITTE 1

1. Montieren Sie die Basis

1. Befestigen Sie das hintere Verbindungsrohr (Nr. 5) und das Verbindungsrohr (Nr. 3) am hinteren Fußrohr (Nr. 1).
2. Befestigen Sie die Fußplatte (Nr. 6) und das vordere Fußrohr (Nr. 2) am Verbindungsrohr (Nr. 3), wobei sich das vordere Fußrohr (Nr. 2) zwischen beiden befindet.



Hinweis: Das vordere Fußrohr (Nr.2) ist kürzer als das hintere Fußrohr (Nr.1).




Wichtiger Hinweis:
Ziehen Sie die Schrauben während der Montage nicht zu fest an, um eine bessere Einstellung zu erreichen!
Ziehen Sie sie erst fest, wenn alles vollständig montiert ist!


MONTAGESCHRITTE 2

2. Montieren Sie den Hauptrahmen

1. Befestigen Sie den Hauptrahmen (Nr. 4) am hinteren Verbindungsrohr (Nr. 5).
2. Befestigen Sie den Hauptrahmen (Nr. 4) am Verbindungsrohr (Nr. 3) und sichern Sie die Verbindung mit dem 13 cm Verstärkungsblech (Nr. 16).



(4)



(16)



(B) x2




(D) x6



(E) x4




(F) x2




MONTAGESCHRITTE 3

3. Montieren Sie die Armstützachse und das Rückenkissen


1. Befestigen Sie das Rückenkissen (Nr. 13) am Hauptrahmen (Nr. 4).
2. Verbinden Sie die Armstützachse (Nr. 12) mit dem hinteren Verbindungsrohr (Nr. 5) und sichern Sie sie mit dem 13 cm Verstärkungsblech (Nr. 16).




(12)



(13)



(16)



(B) x2



(D) x4




(E) x2



(H) x2




(I) x2




MONTAGESCHRITTE 4

4. Montieren Sie die Kurzgriffe

Befestigen Sie die beiden Kurzgriffe (Nr. 10) an den Langgriff-Rahmen (Nr. 9), jeweils einen auf jeder Seite.







MONTAGESCHRITTE 5

5. Montieren Sie die Gewichtsscheibenhalter


1. Befestigen Sie den Hantelscheibenhalter (Nr. 11) am Kurzgriff-Rahmen (Nr. 7) und sichern Sie ihn mit dem 11 cm Verstärkungsblech (Nr. 17).
2. Befestigen Sie den Hantelscheibenhalter (Nr. 11) am Langgriff-Rahmen (Nr. 9) und sichern Sie ihn mit dem 11 cm Verstärkungsblech (Nr. 17).



(11) x4 (17) x4 (A) x8 (D) x16 (E) x8




MONTAGESCHRITTE 5




MONTAGESCHRITTE 6

6. Montieren Sie das Sitzkissen


1. Montieren Sie den verstellbaren Sitzmechanismus (Nr. 18) und das Sitzkissen (Nr. 14).
2. Befestigen Sie das montierte Sitzkissen am Hauptrahmen (Nr. 4).



(14)




(18)





(G) x2



(I) x2










FERTIG

Nachdem alle Schritte abgeschlossen sind, sollten Sie alle Schrauben fest anziehen, um sicherzustellen, dass die Maschine stabil ist, bevor Sie sie verwenden und ausüben.









VORSICHTSMASSNAHMEN BEI DER BENUTZUNG


Hinweis: Um Gewichtsplatten mit einem Durchmesser von 30 mm (1-inch) zu ver wenden, demontieren Sie bitte Teil #11 mit dem L-förmigen Inbusschlüssel.



Seitheben Stehend (Hinteren)




Start




Finish

Seitheben (Hinteren)




Start




Finish

Frontheben Einarmig (Hinteren)



Start



Finish

VORSICHTSMASSNAHMEN BEI DER BENUTZUNG

Hinweis: Fügen Sie beim Ausführen des vorgebeugten seitlichen Hebens oder des sitzenden vorgebeugten seitlichen Hebens keine Gewichtsscheiben am oberen Teil des Geräts hinzu.

Vorgebeugtes Seitheben Stehend (Vorderseite)



Start



Finish

Vorgebeugtes Seitheben Sitzend (Vorderseite)



Start



Finish

1. Trainingsplan & Tipps

Trainingsfrequenz
Experten empfehlen, 3 bis 4 Tage pro Woche Krafttraining zu machen. Wenn Sie natürlich regelmäßiger trainieren, erreichen Sie Ihre Trainingsziele schneller. Stellen Sie sicher, dass Sie in Ihrem Trainingsplan ausreichend Pausen einplanen, damit Ihr Körper Zeit hat, sich zu erholen und zu regenerieren. Nach jeder Trainingseinheit sollten Sie mindestens einen Tag Pause einlegen. Die Regel „weniger ist oft mehr“ gilt auch für Fitness- und Krafttraining. Die Kosten für die Reparatur eines Trainingsgeräts, das nicht ordnungsgemäß gewartet wurde, werden in keiner Weise durch die Garantie abgedeckt.

Trainingsaufzeichnungen
Um Ihr Training zu optimieren und so effektiv wie möglich zu gestalten, sollten Sie vor Beginn des Trainings einen Trainingsplan erstellen, den Sie entweder schriftlich festhalten oder in Ihrem Computer in einer Tabelle anlegen. Hier sollten Sie die Trainingseinheiten und Ihr Gefühl während des Trainings aufzeichnen."

Hier ist ein empfohlener wöchentlicher Plan.

CALENDAR WEEK:_____ YEAR: 20____						
Date	**Exercise**	**Sequence 1**	**Sequence 2**	**Sequence 3**	**Sequence 4**	**Comments**
		___ kg ___Rep	___ kg ___Rep	___ kg ___Rep	___ kg ___Rep	
		___ kg ___Rep	___ kg ___Rep	___ kg ___Rep	___ kg ___Rep	
		___ kg ___Rep	___ kg ___Rep	___ kg ___Rep	___ kg ___Rep	
		___ kg ___Rep	___ kg ___Rep	___ kg ___Rep	___ kg ___Rep	
		___ kg ___Rep	___ kg ___Rep	___ kg ___Rep	___ kg ___Rep	
		___ kg ___Rep	___ kg ___Rep	___ kg ___Rep	___ kg ___Rep	
		___ kg ___Rep	___ kg ___Rep	___ kg ___Rep	___ kg ___Rep	

Erklärung der Begriffe:

Krafttraining besteht normalerweise aus drei oder vier Trainingssequenzen. Jede Trainingssequenz besteht in der Regel aus 10 bis 12 Wiederholungen einer Übung. Am Ende jeder Trainingssequenz sollten Sie eine Erholungsphase von 1 bis 2 Minuten einlegen. Normalerweise werden die im Training verwendeten Gewichte von Sequenz zu Sequenz erhöht."

A Training Session could be as follows:

1. Training Sequence	Training Weight 20 kg	10 Repetitions Break	1 Minute
2. Training Sequence	Training Weight 25 kg	10 Repetitions Break	1 Minute
3. Training Sequence	Training Weight 30 kg	10 Repetitions Break	1 Minute
4. Training Sequence	Training Weight 35 kg	10 Repetitions Break	1 Minute

2. Trainingsempfehlungen

Vorbereitung vor dem Training
Bevor Sie mit dem Training beginnen, stellen Sie sicher, dass nicht nur Ihr Trainingsgerät in einwandfreiem Zustand ist, sondern auch Ihr Körper auf das Training vorbereitet ist. Wenn Sie längere Zeit kein Ausdauertraining gemacht haben, sollten Sie Ihren Hausarzt konsultieren und einen Fitness-Check-up durchführen lassen. Besprechen Sie auch Ihr Trainingsziel; er wird Ihnen sicherlich wertvolle Ratschläge und Informationen geben können. Dies gilt insbesondere für Personen über 35 Jahre, die Übergewicht haben oder Probleme mit dem Herzen oder dem Kreislaufsystem haben.

Trainingsplan
Wesentlich für ein effektives, zielorientiertes und motivierendes Training ist ein vorausschauender Trainingsplan. Planen Sie Ihr Fitnesstraining als festen Bestandteil Ihrer täglichen Routine ein. Wenn Sie keinen festen Plan haben, kann das Training leicht mit regulären Verpflichtungen in Konflikt geraten oder immer wieder auf einen unbestimmten

Aufwärmen vor dem Training
Wärmen Sie sich auf Ihrem Trainingsgerät mindestens 3-5 Minuten lang mit minimalem Widerstand auf. Dies bereitet Ihren Körper am besten auf die bevorstehenden Anstrengungen im Training vor.

Abkühlen nach dem Training
Steigen Sie nicht sofort von Ihrem Trainingsgerät ab, nachdem die Trainingseinheit beendet ist. Wie in der Aufwärmphase sollten Sie auch hier 3-5 Minuten bei minimalem Widerstand weitertrainieren, um sich abzukühlen. Nach dem Training sollten Sie Ihre Muskeln gründlich dehnen.

Trainingssicherheit und Gerätehandhabung

1. Stellen Sie vor Beginn der Trainingseinheit sicher, dass alle Gewichtsstapel, externe Gegengewichte und verstellbaren Teile korrekt montiert und sicher befestigt sind.
2. Gewichtsscheiben dürfen nur hinzugefügt oder entfernt werden, wenn das Gerät stillsteht und auf einer stabilen Fläche steht.
3. Verwenden Sie beim Hantieren mit Gewichtsscheiben stets beide Hände und einen stabilen Stand. Vermeiden Sie Überstreckungen oder plötzliche Bewegungen.
4. Stellen Sie sicher, dass alle Gewichtsscheiben vollständig auf ihren vorgesehenen Stiften sitzen und mit Sicherungsstiften fixiert sind, bevor Sie mit dem Training beginnen.
5. Halten Sie Finger, Hände und andere Körperteile während des Auf- oder Abnehmens der Gewichte von beweglichen Teilen fern.
6. Versuchen Sie niemals, Gewichte zu heben oder zu entfernen, die Ihre persönlichen Kraftgrenzen überschreiten.
7. Überprüfen Sie regelmäßig das Gerät auf Verschleiß oder Beschädigungen, insbesondere Kabel, Rollen, Stifte und Führungen der Gewichtsstapel. Wenn Probleme festgestellt werden, stellen Sie die Nutzung sofort ein und wenden Sie sich an den Kundendienst.



Vordere Oberschenkelmuskeln
Stützen Sie sich mit Ihrer rechten Hand gegen die Wand oder auf Ihr Trainingsgerät. Beugen Sie Ihr Knie und heben Sie Ihren linken Fuß nach hinten, sodass Sie ihn mit Ihrer linken Hand halten können. Ihr Knie sollte gerade nach unten zum Boden zeigen. Ziehen Sie Ihr Bein nach hinten, bis Sie ein leichtes Ziehen in Ihren Oberschenkelmuskeln spüren. Halten Sie diese Position 10 bis 15 Sekunden. Lassen Sie Ihren Fuß los und stellen Sie ihn wieder auf den Boden. Wiederholen Sie die Übung mit Ihrem rechten Bein.



Innerer Oberschenkelmuskeln
Setzen Sie sich auf den Boden. Ziehen Sie die Sohlen Ihrer Füße vor sich zusammen und heben Sie Ihre Knie leicht an. Fassen Sie die Oberseiten Ihrer Füße und legen Sie Ihre Ellbogen auf Ihre Oberschenkel. Drücken Sie mit Ihren Armen Ihre Oberschenkel nach unten in Richtung Boden, bis Sie ein leichtes Ziehen in Ihren Oberschenkelmuskeln spüren. Halten Sie diese Position 10 bis 15 Sekunden. Achten Sie darauf, Ihren Oberkörper während der gesamten Übung gerade zu halten. Lassen Sie den Druck von Ihren Oberschenkeln los und strecken Sie langsam Ihre Beine nach vorne aus. Stehen Sie langsam und gleichmäßig auf.



Beine, Waden und Gesäß
Setzen Sie sich auf den Boden. Strecken Sie Ihr rechtes Bein aus und beugen Sie Ihr linkes Bein, sodass die Sohle Ihres Fußes auf Ihrem rechten Oberschenkel liegt. Beugen Sie Ihren Oberkörper nach vorne, um mit Ihrer rechten Hand Ihre rechten Zehen zu berühren. Halten Sie diese Position 10 bis 15 Sekunden. Lassen Sie Ihre Zehen los und setzen Sie sich langsam und gleichmäßig wieder aufrecht hin. Wiederholen Sie diese Übung mit Ihrem linken Bein.



Bein- und untere Rückenmuskeln
Setzen Sie sich auf den Boden mit ausgestreckten Beinen. Beugen Sie sich nach vorne und versuchen Sie, mit beiden Händen die Spitzen Ihrer Zehen zu greifen. Halten Sie diese Position 10 bis 15 Sekunden. Lassen Sie Ihre Zehen los und setzen Sie sich langsam und gleichmäßig wieder aufrecht hin.

GARANTIE

Um Ihr Produkt zu registrieren, senden Sie bitte eine E-Mail mit Ihrer Bestellnummer und einem Bildschirmfoto Ihrer Bestellung an **service@hvofitness.com** Dieser Schritt stellt sicher, dass Ihr Produkt ordnungsgemäß in unserem System registriert ist und Ihre Garantie aktiviert wird.

❶ Sollten Sie Probleme mit Ihrem Produkt haben, können Sie neue und ungeöffnete Artikel innerhalb von 30 Tagen nach der Lieferung zurücksenden und erhalten eine volle Rückerstattung oder Ersatz.

❷ Registrieren Sie Ihr Produkt, indem Sie Ihre Bestellnummer an unsere spezielle E-Mail-Adresse für den Kundendienst **service@hvofitness.com** senden. Bei Aktivierung der Garantie erhalten Sie unsere Standard-Garantie von 6 Monaten plus weitere 180 Tage, so dass Sie ein Jahr lang abgedeckt sind.


❸ Während der Garantiezeit sind Reparaturen (mit Ausnahme von Verbrauchsmaterialien) kostenlos, aber der Kunde trägt die Kosten für den Hin- und Rückversand.


❹ Wenn die Garantie für Ihr Produkt abläuft, stellen wir Ihnen nach bestem Wissen und Gewissen Lagerzubehör zur Verfügung, um Sie bei der Reparatur zu unterstützen (hierfür können Gebühren anfallen).

❺ Wenn Sie das Produkt selbst verändern und versuchen, es zu reparieren, erlischt die Garantie.

❻ Aufgrund von Distributionsprozessen kann das Produkt während des Versands etwas Reibung und raue Behandlung erfahren. Wir empfehlen Ihnen, den Verpackungskarton aufzubewahren, falls eine Rücksendung erforderlich ist. Ohne das Verpackungsmaterial ist eine Rückgabe möglicherweise nicht möglich.

Product Details	
Item name	HVO STANDING LATERAL RAISE MACHINE
Model	LR1201
Contains	HVO STANDING LATERAL RAISE MACHINE*1 + INSTRUCTIONS *1





quefairedemesdechets.fr
Privilégiez la réparation ou le don

EU REP

SUCCESS COURIER SL
CALLE RIO TORMES NUM. 1, PLANTA 1, DERECHA, OFICINA 3, Fuenlabrada, Madrid, 28947 Spain
successservice2@hotmail.com

OST_EU_20230129000004

We simply act as EU representative for cross-border sellers, and are not manufacturers/importers/distributors for the product, nor involved in the manufacture/import/sale of the product. Therefore, we are not responsible for any after-sales services related to the product. In case of any product quality or infringement issues, the manufacturer/importer/seller shall be solely held responsible.

Manufacturer: Guangzhou Fengjin Trading Co., Ltd.
Address: tianyuanlu804hao, dayuannei17dongzibianA03-10 (Y40shi), Guangzhoushi, Tianhequ,Guangdong,China

Version: 26LR1201008

HVO®

HVOFITNESS.COM

FOR QUESTION
SCAN CODE
USE PHONE CAMERA

Web: HVO

Youtube: HVO

Instagram: HVO

Email: service@hvofitness.com
Reddit: #HVOFitness / #HVOFitnessCommunity