Product Manual

Massage Chair

Z6OCAM0813



CONTENTS

Safety Precautions · · · · · · · · · · · · 1

Exploded Diagram · · · · · · · · · · · · 2

Product Description · · · · · · · · · · · 3–10

Trouble-shooting · · · · · · · · · · · · 11

Product SpeciPcations · · · · · · · · · · · · 12

Care & Maintenance · · · · · · · · · · · · 13

CARE & MAINTENANCE

Cleaning

1. Do not use steel wool, abrasive cleaning agents or corrosive liquids (such as gasoline or acetone) to clean the product.
2. Unplug the plug from the power socket.
3. Wipe with a dry cloth to clean the product, control panel and power cord.
4. Do not use a damp cloth or detergent.

Storage

1. Unplug the plug from the power socket.
2. Store the product in a cool dry place away from sunlight.
3. Do not put a heavy weight load on the product.

If the cover is damaged or there is any mechanical failure, please stop using the product. Contact or its authorised dealers immediately.


PRODUCT SPECIFICATIONS

Product Name	Massage Chair
Model Number	Z6OCAM0813
Type of Product	Massage Chair
Adapter	Input:100-240Vac. 50/60Hz, 0.8A Output: 12Vdc, 3A
Battery	DC14.8V, 5000mAh, 74Wh
Power Consumption	36W
Product Dimension	Approx. 708 x 730 x 1155 mm 30.25"L × 28.75"W ×45.5"H
Box Dimension	Approx. 830 x 350 x 620 mm 32.75"L × 13.75"W ×24.5"H
Net / Gross Weight	Approx.24/27kg
International Safty Compliance	CE

SAFETY PRECAUTIONS

1. People with the following conditions should consult their physician before using the product:
   - Who uses a medical electronic device, which is embedded in the body, such as a pacemaker.
   - Who suffers from heart disease.
   - Who suffers from backbone injury or disease.
   - Who is suffering from bone fragility, especially on the backbone.
   - After surgery.
   - Who is pregnant or shortly after delivery or in a period of monthly illness.
   - Who suffers from malignant tumors.
   - Who is suffering from osteoporosis.
   - Who is suffering from blood circulation problems or thrombosis.
   - Who is suffering from skin disease or infection.
   - Who is undergoing medical treatment or feels some physical abnormality previously or is being treated now.
   - Who has some abnormality or deformity of limbs or backbone.
   - Who has injuries, diseases due to illness or accident.
2. Do not let water enter the product or be splashed near the surface of the product.
3. Water contact with electricity is dangerous. Do not leave the product in a humid environment (such as in the bathroom or shower room or swimming pool).
4. Before connecting the product to the power supply, check that the product voltage and supply voltage are the same.
5. If the plug, power cord or product itself is damaged, do not use the product.
6. In order to prevent the risk of electric shock, do not open the product outer cover.
7. Product is not intended for use by the disabled, sensory or mentally impaired persons (including children), unless there is supervision or guidance by the people responsible for their safety when they use the product.
8. If the product or power cord is damaged, do not repair it yourself. Only qualified technicians may perform repairs, or the warranty will be void.
9. Children should not use this product. They should be under supervision to ensure that they will not treat this product as a toy.
10. If an unusual sound or noise is being heard from the product, turn off the product and immediately disconnect the power connection. Please contact us or its authorised dealers immediately.
11. Do not use the product if cover is damaged or if there is a mechanical or electronic failure. Please contact its authorised dealers.
12. Only use or place the product in accordance with the instructions in this user manual.
13. Do not use this product in high temperature conditions or beside hot objects such as heaters, stoves.
14. Do not apply medical or cosmetic cream on the product or on your body before using or during the use of this product.
15. Do not destroy, bend, stretch, twist or tie the power cord. Damaged power cord can cause fire or electric shock.
16. When massaging around or near the neck, take note of the movement of rollers and refrain from using excessive intensity.
17. Recommended usage time for an individual is 15 minutes at a time.
18. Please remove all accessories on body before use.
19. This product is intended for household use only.
20. Do not use the product while sleeping, when drunk, or during a fever.
21. Avoid using the product immediately after eating. Wait for at least an hour before using the product.
22. Do not leave the product in direct contact with your skin.

Exploded Diagram




Two persons

TROUBLE-SHOOTING

This page summarises the most common problems you would encounter with the product. If you are unable to solve the problem with information below, please contact or its authorised dealers immediately.


Problem	Possible Cause	Suggestion
The product does not work	The product is not plugged in properly.	Ensure the voltage on the product corresponds to the local mains voltage and then plug in again. Then turn on the power switch.
	The product has just finished its 15-min auto timer session and has automatically switched to standby mode.	If you want another session, press the On/off button again.
	You may have used the product continuously for more than 45 minutes and the overheat protection has been activated.	Unplug the product and let it cool down for 60 minutes before you use it again.
	An excessive load has been applied on the product.	Reduce the excessive load and start again.
The product is abnormally warm	The product is likely to be overused.	Unplug the product and let it cool down before using it again.
Noise can be heard from the product	Noise is made by the mechanical parts of the product.	This is normal and does not mean that the product is faulty.

Operating Instructions



Button	Indicator Light	Function Description
ON	○	Press and hold this button for about 2 seconds to activate full back massage mode. The massage mechanism moves up and down along the backrest. Press the button again to pause massage. The indicator light stays steadily on.
OFF	◑	Press and hold this button for about 2 seconds to turn off the massage function. The massage mechanism will automatically return to the bottom of the backrest. The indicator light flashes.
Note: The massage will be turned off automaticly after a 15 mins program. Please press on again to restart.		

Adapter charging status



Adapter charging status: ging: Blue light is on;

Char

Charging completed: Blue light goes off;

Low battery level: The blue light flashes.





Charging time: 3 hrs, Battery Life: 90 min

Note: Do not use the massage function while charging the chair.



PRODUCT DESCRIPTION

1.Product Installation

1).Parts List


A x 1  Backrest	**B** x 1  Seat	**C** x 1  Mechanism
D x 1  Gas Lift	**E** x 1  Leg Base	**F** x 1 placed on the Leg Base(E)  Base Cap
G x 5  Leg	**H** x 5  Caster	

2).Hardware List

1 x 21+1  Blot M6*20mm	**2** x 4  Flat Washer	**3** x 1  Allen Key #5
4 x 1  Adapter		

2.Product Installation Steps

Step 1




Take off the cap


Step 2

1		x 5
3		x 1

Note:
Nest and align the holes of five-star base, then tighten the screws.




Adapter charging status




Adapter charging status：
Charging: Blue light is on;
Charging completed: Blue light goes off;
Low battery level: The blue light flashes
Charging time: 3 hrs, Battery Life: 90 min

Height Adjustment Lever



To raise the seat: Pull the lever upward and slightly
lift your hips to raise the s eat.
To lower the seat: Pull the lever upward and apply
downward pressure on the sea t cushion to lower the seat.
The seat height adjustment range is approximately 70mm

Recline Adjustment Lever




Pull the lever outward and apply pressure against the backrest to recline it. Release the pressure,
and the backrest returns to its original position.
Push the lever inward to lock the backrest from reclining.

Step 3

H		x 5


Step 4



Step 5


1		x 12
3		x 1

Note :
Fully tighten the bolts in sequence after all bolts proper connected.




x 2

Step 6



Step 7

1		x 4
2		x 4
3		x 1



Note :
Fully tighten the bolts in sequence after all bolts proper connected.

Step 8

