




ITEM NO. ETHD1468

Scan for manual,
video & advice.



If you have any questions or concerns,
don't hesitate to reach out to us.

Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)
Email: customerservice@hulalahome.com

MAINTENANCE AND WARNINGS

Thank You For Choosing Our Furniture.


Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

NOTE :

This brochure contains IMPORTANT safety info. Please read and keep it for future reference.



Weight Limitation
80 LBS



Installation:
15 minutes.



Two Person



Before You Start

Please follow the steps below:

-  Unbox the package and check if all parts and accessories are complete.
-  If you find something missing, stop assembly and contact your supplier immediately.
-  Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.
-  NOTE: Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.



Warranty


- ⚠ We strive to offer high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.
- ⚠ Are you having difficulty with assembly? Missing parts? Please send email with your order number to **customerservice@hulalahome.com**
- ⚠ For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance

- Keep furniture away from heat.
- Do not use cleaning agents containing acids, alkalis, or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, for residential use only.


Exploded Diagram

Please confirm that you have received all the parts in the box and start the installation.




Parts List

A ×1



cabinet body

B ×1




Shelf board

C ×4



Legs


D ×1



power strip


Hardware List

1 ×4




Anti-tip component

2 ×4




Self-tapping screw
D4x20

3 ×2




Hardware pack

4 ×4




Expansion pipe
L30mm

5 ×4




Self-tapping screw
D4*40

6 ×1




Screwdriver

7 ×1



Hex wrench
M4

8 ×4+1



three in one
M6x35mm

9 ×4+1



tree top
Ø8*30mm

10 ×4+1




eccentric wheel

11 ×4+2



Huamei Patch

12 ×1




Socket

13 ×4+1



Self-tapping screw
D4*25mm

14 ×2




Self-tapping screw
D4x14mm

15 ×4+1



Gasket

16 ×4+1




Screw
D6x40mm

ASSEMBLY INSTRUCTIONS

Step 01


As shown in the figure: Use the screwdriver (6) to lock the three-in -one pole (8) into the hole corresponding to the foot (C)


8	 x 4	M6x35	6	 x 1	Screwdriver
---	---	-------	---	---	-------------



Step 02

As shown in the figure: Insert the eccentric wheel (10) into the corresponding hole of the layer plate (B) and tighten it with the screwdriver (6). Then, stick the masking tape (11) onto the corresponding hole of the layer plate (B).


10	 x 4	Ø15x9mm	11	 x 4	Huae Patch
6	 x 1	Screwdriver			



Step 03

As shown in the figure: Insert the tree top (9) into the corresponding holes of the cabineg body (A) and the feet (C).


9	 x 4	Ø8x30mm
---	---	---------



Step 04

As shown in the figure: Insert screw (16) through the flat washer (15), the cabinet (A), and the foot (C), and assemble them together. Then, use wrench (7) to lock it in place.


15	 x 4	Gasket	16	 x 4	M6x40mm
7	 x 1	M4			



Step 05


As shown in the figure: Pass the socket (12) through the socket plate (D), and use the screw (14) to pass through the socket (12) and the socket plate (D) to assemble them together. Then, use the screwdriver (6) to lock it in place.


14	 x 2	D4x14mm	12	 x 1	Socket
6	 x 1	Screwdriver			




Step 06

As shown in the figure: Pass screw (13) through the socket board (D) and assemble it with the cabinet (A), then tighten it with screwdriver (6).

13		x 4	D4x25mm	6		x 1	Screwdriver
----	---	-----	---------	---	---	-----	-------------




Step 07




Note:
Before the next step, adjust the feet of
the locker to keep it level.

Step 08



Pass screw (2) through the anti-tilt part (1) and attach it to the corresponding position on the cabinet panel, then tighten it with screwdriver (6).



2	 x 4	D4x20mm
1	 x 2	Anti-tip componeng
6	 x 1	Screwdriver




Step 09

Install Anti-tip device (1) to the wall in this step.


5	 x 4	D4x40mm	1	 x 2	Anti-tip componeng
4	 x 4	L=30mm	6	 x 1	Screwdriver



1. Drill a hole in the wall with an electric drill.



2. Tap the plastic wall anchor into the hole with a hammer.



3. Secure the Anti-tip device 1 to the wall with screws 5.




Step 10

WARNING

Children have died from furniture tipover.

To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- For use with televisions weighing 35 lb or less. Use with heavier televisions may result in instability causing tip-over resulting in death or serious injury.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.



WWW.HULALAHOME.COM

Email: customerservice@hulalahome.com

Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)