



1/18 FORD F-100

Quick Start Guide

A1


快速指南



Scan the QR code to view the complete instruction manual.
扫码阅读完整说明书



Scan the QR code to access the official website of FMS.
FMS



IMPORTANT 重要

Read this Quick Start Guide and the full instruction manual before use.
Retain both documents for future reference.

在使用前请先阅读这份快速指南以及扫码阅读完整的说明书。

并予以妥善保存,以备日后参考。

MAN-G0354

BRUSHLESS 无刷

MADE IN CHINA



1

⚠ WARNING 警告

This product is **not a toy**
此产品不是玩具!

Recommended for users **14 years of age and older**.
Users under 14 must operate under adult supervision.
Contains small parts. Keep away from children under 3 years of age.
此产品推荐给 14 岁及以上的用户使用。
14 岁以下的用户必须在成人监护下操作。
此产品包含小部件,可能会造成窒息危险。请将产品放置在 3 岁以下儿童无法触及的地方。

PACKAGING INCLUDES

包装包含



1 X 1/18 Ford F-100 Vehicle
1 X 1/18 Ford F-100 攀爬车




1 X Surfboard
Accessory
1 X 冲浪板



1 X 2.4GHz
Transmitter
1 X 2.4 GHz 遥控器



1 X 2S LiPo 7.4 V
900 mAh Battery
1 X 2S 7.4 V 900
mAh 锂电池



1 X USB Balance
Charger
1 X USB 充电器



1 X 1.5 mm Hex
Wrench
1 X 1.5 mm 六角匙









1 X Cross Wrench
1 X 十字套筒



1 X Decal Sheet
1 X 贴纸

VEHICLE FEATURES OVERVIEW

车辆的功能说明




2


TRANSMITTER BATTERY INSTALLATION AND POWER-ON/OFF INSTRUCTIONS

遥控器电池安装与开关机说明


Install the transmitter batteries and operate power on/off as follows. Requires: 4 × AAA Batteries(not included).
请按照以下步骤安装遥控器电池及操作遥控器的开机与关机, 电池使用类型: AAA 电池*4PCS (产品内不包括)




1. Open the battery compartment cover on the bottom of the transmitter.
1. 从遥控器底部打开电池仓盖。




2. Insert four AAA batteries, observing correct polarity.
2. 将4节1.5V的AAA电池按正确极性装入。



3. Close the battery cover securely. Remove batteries if not used for extended periods.
3. 合上电池仓盖。如果长时间未使用, 请取出电池。



4. After installing the AAA batteries, slide the power switch to the ON position; a solid red R.LED indicates the transmitter is powered correctly. If the R.LED does not light, the batteries are reversed or low.
4. 遥控器装上AAA电池后, 将电源开关拨到[ON] 位置, R.LED 灯为红色灯常亮为开机OK, 若开机R.LED不亮起, 表示电池装反或电池电量不足。



5. Slide the power switch to OFF; the R.LED turning off indicates the transmitter is powered down.
5. 将电源开关拨到 [OFF] 位置, R.LED 灯熄为遥控器关机状态。

TRANSMITTER SLEEP MODE 休眠模式

After binding the transmitter to the vehicle's receiver on power-up, you can operate all vehicle functions. If there is no input for 10 minutes, a "B-B-B" beep will sound and the transmitter enters sleep mode; cycle the power to wake it.


遥控器与车辆的接收机开机对码成功后, 就可以进行车辆功能操作了, 如无任何操作, 10分钟后, 会有"B-B-B"蜂鸣声, 遥控器进入休眠模式, 须重启遥控器才可退出休眠模式。

3


VEHICLE BATTERY INSTALLATION AND POWER ON/OFF INSTRUCTIONS

车辆电池安装与开关机说明


Install the vehicle battery and operate power on/off as follows.
Battery type: 2S LiPo 7.4 V 900 mAh Battery ×1.
Note: Always switch on the transmitter first and then the vehicle; when powering down, turn off the vehicle first, then the transmitter.
请按照以下步骤安装车辆电池及操作车辆的开机与关机, 电池使用类型: 2S 7.4 V 900 mAh 锂电池 ×1
注: 开启车辆时请务必先开启遥控器再开启车辆, 关闭车辆时请务必先关闭车辆开关再关闭遥控器开关。




1. Remove the body shell from the magnetic mounts.
1. 稳住车架, 向上打开车壳, 使车壳与车架分离。




2. Install the battery in the battery tray and secure it with a tie.
2. 将电池安装到电池托盘中, 并用硅胶扎带固定好。



3. Connect the battery lead securely. the power connector is keyed for reverse-polarity protection. Ensure correct orientation — forcing it may cause a short circuit.
3. 将电池与电调连接, 电池的电源线接口有防反装设计, 请注意插入方向, 强行反插会引起短路。



4. Press the power button; The red receiver LED indicates the vehicle is powered on. Press the button again and the LED turns off to power down the vehicle.
4. 按下电源按钮; 红色接收器指示灯亮起表示车辆已通电。再次按下按钮, 指示灯熄灭, 表示车辆已关闭电源。



5. Reinstall the body shell. Ensure the battery lead faces forward inside the chassis.
5. 电池一端是车头, 车壳与车架对准两端的磁吸位置, 将车壳重新合装于车架。确保电池导线朝前放置在车底内部。

4

