
Niidel™ pod

Scan this QR code for more info, manuals, spare parts, inspo and so much more

PUSH TROLLEY

Step by Step Instructions




COLOUR ME IN!


LEVEL 1

All Play Pieces


01




02




03



04



05




06




07




08




09



10




11



12



13



14 15 16 17 18 19 20 21 22 23 24 25 26 27




28



29




30




Pieces You Need

x1




01

x2



03

x4




04

x4




11

x4



16

x12





25

WARNING


This product can cause injury if not used safely. Supervise children at all times. An adult must assemble the product fully before giving to a child. Screws and components pose a sharp point and choking hazards.


1.






2.







3.



10





YAY! WELL DONE!