

Assembly Instructions

An adult must assemble the product fully before giving to a child.




Play Pieces



01. Big Box x 1
02. Removable Lid x 1
03. Curved Arms x 2
04. Wood Wheels x 4
05. L Arms x 2
06. Velcro Patches x 6
07. Velcro Straps x 12
08. Play Silk x 1
09. Wood Dowel Short x 4
10. Wood Dowel Medium x 6
11. Wood Dowel Long x 6
12. Connector Tubes x 2
13. Play Tubes x 2
14. Key Pegs x 6
15. T Pegs x 6
16. Hashtags x 12
17. Cogs x 3
18. Pine Trees x 2
19. Jumping Character x 1
20. Horse Character x 1
21. Cross Character x 1
22. Standing Character x 1
23. Star Character x 1
24. Fish Character x 1
25. Silicone Rings x 22
26. Wood Ball x 1
27. Felt Ball x 1
28. Castor Wheels x 4
29. 56 Inspiration Cards x1

Hammock Pack Add-On


01. Curved Arms x 2
02. Hammock Piece



Niidel pod™

Scan this QR code for more info, manuals, spare parts, inspo and so much more

IMPORTANT INFORMATION AND WARRANTY



WARNING

This product can cause injury if not used safely. Supervise children at all times. An adult must assemble the product fully before giving to a child. Screws and components pose a sharp point and choking hazards.

©2024 Nüdel Pod by Playground Ideas Reg. Des. 202410800/202410801 – NK0 V2

WARNING:

- This product can cause injury if not used safely. Supervise children and assess risk at all times.
- Use of the Nüdel Pod must always be supported by the presence an adult.
- An adult must assemble the product fully before giving to a child. Screws and components pose a sharp point and choking hazards.
- Nüdel Pod has been designed for children aged 1 year and older. Children under the age of 12 months should not be permitted to engage in play with the Nüdel Pod.
- Maximum 1 user.
- Maximum weight 50kg (unless marked).
- Use on a flat ground, clear of obstructions.
- Do not place this product near windows to avoid falls and tangles in window coverings.
- Do not allow children to build high constructions for climbing or constructions which could hurt if they fell upon them.
- Damaged parts must be discarded, repaired or replaced before reuse.
- Serious injury may result as a consequence of not following this information.

The Nüdel Pod can be configured in millions of different ways and so might present different risks and hazards to different ages of children, with varying levels of competency and development. Adults should actively monitor risk (www.nudelkart.com/nk-risk-benefit-assessment for more information on Risk Benefit Assessment and access to our template.)

Take care when using Nüdel Pod with other equipment or with objects other than those supplied – assessment of additional risk is essential. Go to the website at www.nudelkart.com/nk-risk-benefit-assessment.

TO AVOID SERIOUS INJURY: Continuous adult supervision required. Never use near motor vehicles; Never use near streets, swimming pools, hills, steps, or sloped driveways; Always wear closed shoes when using the Nüdel Pod.

The Nüdel Pod is designed to be used indoors or outdoors in dry conditions. Your Nüdel Pod is made from natural timber and not designed to be used in wet, excessively humid, dusty, muddy or moist conditions and should not be left outside overnight.

Regularly inspect all parts for signs of visible damage or wear and tear that indicates a broken or weakened part. Damaged parts must be removed from a child's reach, discarded, repaired or replaced.

Wipe the Nüdel Pod clean with a damp cloth before the first use and after each subsequent use. Hand wash fabrics and felt balls before first use.

You can restock with Nüdel Pod spare parts. Visit https://nudel.shop

NÜDEL PRODUCTS ONE (1) YEAR MANUFACTURER'S WARRANTY

1. Manufacturer's warranty details

We warrant our products against defects in materials and workmanship when used normally in accordance with our Terms of Use for a period of one (1) year from the date of original retail purchase by the end-user purchaser (Warranty Period). Our Terms of Use can be found on our website here: https://www.nudelkart.com/terms-of-use.html

If during the Warranty Period you submit a claim to us in accordance with this warranty, we will:

- repair or replace the part using new or previously used parts that are equivalent to new in performance and reliability;
- replace the product with the same model formed from new and/or previously used parts that are equivalent to new in performance and reliability, or
- exchange the product for a refund of your purchase price.

Before receiving a repair, replacement or refund under the terms of this warranty, we may require that you provide proof of purchase details and respond to questions designed to assist with diagnosing potential issues.

The product will need to be returned to us at the customers expense.

This is offered in addition to the statutory guarantees under the Australian Consumer Law.

2. What this means for you: Our products …

2.1. … are designed to be long-lasting

Our products are designed for active use in many settings, including both indoors and outdoors. Our products are made from durable materials and are designed to be long-lasting, even with heavy use. They are primarily made from AAA grade plywood, food grade silicon and other durable materials.

Please refer to our Terms of Use and manuals for more information on our expectations concerning the use, supervision, construction and pack-up of the product. These manuals contain important information to ensure product longevity.

As noted above, our warranty covers defects in materials and workmanship. This does not include damage caused by:

- operating the product outside the Terms of Use, including by accident, abuse, misuse or other external cause; or
- normal wear and tear due to the normal aging of the product (for example, cosmetic damage, including but not limited to scratches, scuffing, dents or chips).

2.2. … are intended to be maintained

Everything in our product is maintainable or replaceable individually. Our product is like a car, with regular maintenance and care it will give you faithful service day after day.

If the Nüdel Pod experiences long periods of sunlight, moisture or humidity, it may reduce the longevity of the product, if you experience this or any other damage that cannot be repaired please get in contact with us and we will advise you of other possible maintenance solutions. This advice is designed to increase the Nüdel Pod's lifespan and lessen its impact on the environment and the waste stream for future generations.

2.3. … come with many individual parts

As our product is made up of separate and individual pieces, and includes multiple additional spare critical parts required for Pod pack up and loose parts play, it is not rendered unusable if a single part becomes damaged or lost. It is likely that a repair or replacement of a single piece will fix the problem and use is more appropriate in most circumstances.

If you experience a broken piece, please get in contact with us. We will ask you to either: send back the broken piece and we will assess the piece for a repair or replacement, or just send us a photo. In the meantime, the remaining pieces are still fully usable as intended.

3. Our promise to you

We want our customers to have the best possible experience with our products. We are here to help you through any questions or queries you may have, including by organising repairs, replacements or further training on how best to use our products.

If you have any concerns regarding our products, please do not hesitate to get in contact with us by email: pod@nudel.shop

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Visit our website: https://nudel.shop