
Niidel pod™

Scan this QR code for more info, manuals, spare parts, inspo and so much more

TENT

Step by Step Instructions



*Requires Hammock Pack


★★★

COLOUR ME IN!


LEVEL 3

All Play Pieces


01




02




03



04



05




06




07




08




09



10




11



12



13



14 15 16 17 18 19 20 21 22 23 24 25 26 27




28




29



30




Pieces You Need



x4

03



x2

05




x2

17




x20

25



x5

11




x1


08

WARNING

This product can cause injury if not used safely. Supervise children at all times. An adult must assemble the product fully before giving to a child. Screws and components pose a sharp point and choking hazards.


1.







2.









3.




6






4.



2







5.



1




1






6.




6







7.




8




2







8.



1





YAY! WELL DONE