



R026

# Use and Care Instructions

PLEASE READ USE AND CARE INSTRUCTIONS IN ITS ENTIRETY  
PRIOR TO SETTING UP AND OPERATING YOUR RETROLIFE PRODUCT

*NOTE: As with any electronics maintenance, always unplug the unit from the power outlet to prevent the risk of electrical shock.*

Retrolife R026 is a retro gramophone with trumpet shape, bringing you nostalgic music experience and unique decoration style. In order to ensure that you can enjoy the wonderful music brought by this gramophone for a long time, here are some suggested use and maintenance methods:

## 1.Placement:

Place the R026 phonograph on a solid surface to ensure its balance and stability. Please keep away from direct sunlight, high temperature, humidity and dusty environment, so as to protect its appearance and internal structure.

## 2.Using the stylus:

Please make sure the stylus is in good condition before use, avoid using old and worn stylus, so as not to cause damage to the record and affect the sound quality. Check the stylus regularly for wear and replace as necessary.

## 3.Record storage:

Before playing the record, please check whether the record is clean, if there is dust or dirt, use a professional record cleaning tool to gently clean it. When you're done playing, store your records in their sleeves or racks out of direct exposure to dust and sunlight.

## 4.Adjustable RPM:

The R026 supports playback speeds of 33 $\frac{1}{3}$ ,45 and 78 revolutions per minute (rpm). When playing records with different RPM, make sure to adjust the RPM switch to match the record's requirements for the best sound quality.

## 5.Cleaning and maintenance:

Regularly clean the external surface of the phonograph and the shape of the horn, wipe it with a soft clean cloth, and avoid using cleaners containing alcohol or corrosive substances. Pay special attention to the maintenance of the shape of the horn, and avoid using too wet cleaning tools.

## 6.Adjust the volume:

R026 is equipped with a built-in speaker, please adjust the volume moderately when using it, and avoid excessively high volume for a long time to protect the speaker and your hearing.

## 7.Avoid Overtime Use:

While the R026 is designed to be durable, in order to prolong its life, please avoid overtime use of the phonograph. After each use, please turn off and unplug the power plug.

## **8.Maintenance of the power cord:**

Regularly check whether the connection of the power cord is firm, and avoid the power cord from being stressed or twisted to ensure safe use.

Follow these usage and care recommendations, and you'll be able to enjoy the nostalgic music experience and unique decorative style brought by the Retrolife R026 for a long time. Make this vintage phonograph with horn a unique addition to your music life.

*Retrolife offers a product line of various cleaning accessories. Please visit our website at <https://retrolifeplayer.com/collections/accessories> for more information. As products are improved and new products are released, our Use and Care Instructions are regularly updated on corresponding pages and <https://retrolifeplayer.com/pages/help-center>*