



Use and Care Instructions

PLEASE READ USE AND CARE INSTRUCTIONS IN ITS ENTIRETY
PRIOR TO SETTING UP AND OPERATING YOUR RETROLIFE PRODUCT

NOTE: As with any electronics maintenance, always unplug the unit from the power outlet to prevent the risk of electrical shock.

The Retrolife R609 is a beautiful retro luggage turntable that brings you the perfect combination of nostalgia and style. In order to ensure that you can enjoy the great music experience brought by this turntable for a long time, here are some suggested use and maintenance methods:

1.Placement:

Place the Retrolife R609 on a solid surface and make sure there are no obvious vibrations and shocks around it. Avoid placing the turntable in direct sunlight, high temperature, humidity, or dusty environments to protect its exterior and internal construction.

2.Using the stylus:

Please make sure the stylus is in good condition before use, try to avoid using old and worn stylus, so as not to cause damage to the record and affect the sound quality. Check the stylus regularly for wear and replace as necessary.

3.Record storage:

Before playing the record, please check whether the record is clean, if there is dust or dirt, use a professional record cleaning tool to gently clean it. At the same time, when the record is not being played, it should be kept in a record sleeve or a record stand to avoid direct exposure to dust and sunlight.

4.Adjusting the RPM:

The Retrolife R609 supports playback speeds of 33 $\frac{1}{3}$, 45 and 78 revolutions per minute (rpm). When playing records with different RPM, make sure to adjust the RPM switch to match the record's requirements for the best sound quality.

5.Cleaning and Maintenance:

Regularly clean the exterior surface of the record player and the acrylic cover, wipe with a soft, clean cloth, and avoid using cleaners containing alcohol or corrosive substances. Internal maintenance is recommended to be carried out by professional technicians.

6.Avoid Overtime Use:

While the Retrolife R609 is designed to be durable, to prolong its life, please avoid overuse of the turntable. After each use, please turn off and unplug the power plug.

7.Maintenance of the power cord:

Regularly check whether the connection of the power cord is firm, and avoid the power cord from being stressed or twisted to ensure safe use.

Follow these usage and care recommendations, and you'll be able to enjoy the beautiful music brought by the Retrolife R609 for a long time, making this retro leather turntable an indispensable companion on your music journey.

Retrolife offers a product line of various cleaning accessories. Please visit our website at <https://retrolifeplayer.com/collections/accessories> for more information. As products are improved and new products are released, our Use and Care Instructions are regularly updated on corresponding pages and <https://retrolifeplayer.com/pages/help-center>