







ASSEMBLY INSTRUCTION






Accent chair
TN-3694




Component List

LABEL		DESCRIPTION	QTY
A		Seat	1
B		Back	1
C		Arm	1
D		Wood crosspiea	1
E		Back cushion	1

Hardware List


LABEL		DESCRIPTION	QTY
H1		SCREW M6×50mm	2
H2		SCREW M8×50mm	6
H3		Spring washer M8	6
H4		Flat washer M8×22×1.5mm	6
H5		Allen key M6	1

1




Tighten the screws to 80% tightness.

2




Tighten the screws to 80% tightness.

3



Tighten the screws to 80% tightness.

4



Adjust the chair so that it is leveled, then fully tighten all the screws.