## T1S英文说明书


尺寸:100X100mm


材质:80g书纸

工艺:四色印刷


备注:两折正反面








100mm





## **Working Mode**

- 1. Short press the "On/Off" button, the device will start to work.
- 2. Quickly press the on/off button and switch to low speed mode. Then quick press again and switch to the high speed mode.
- 3. Work for 8 minutes, stand by for 3 minutes (Follow 3 Cycles)

  Note: The LED Light will be activated by any movement.

## **Product Paramaters**

Rotating Cat Teaser
T1
170 x 170 x 134mm
ABS、PC
White + Robin-Egg Blue
310g
3* AA Dry Battery / Button Battery (LR41)