


折页尺寸: 60x105mm

正面

IENYRID
iE-YF001
Belt motor
off-road skateboard




USER MANUAL


Thank you for buy our electric skateboard
Do note that an electric skateboard is not a toy. Please take time to learn it and read this manual carefully. Particularly the safety instruction pages.
We hope you will enjoy this product and have lots of fun with it in the future

1


PREPARATION




1. Be sure that wear a helmet and safty gear when you ride it




2. Confirm the front direction of the skateboard



3. Confirm the position on the skateboard, The feet stand on the widest front and back skateboard.




4. Please start with the low speed mode to be familiar with the accelerate and brake of the skateboard.



5. Please stop riding by remote control brake operation, then get down your front foot at first and then get down your back foot.

2


PARTS DIAGRAM



- 1 Front wheel
- 2 Front Truck
- 3 Deck
- 4 Battery indicator
- 5 Charge port
- 6 Charge interface
- 7 Heat sink hole
- 8 Hub motor wheel
- 9 A belt cover
- 10 Battery case

3

REMOTE CONTROL




- Speed control ▲ Accelerate
● Brake
- Speed mode toggle ▲ High
● Middle
▼ Low
- Power switch
- Reverse button
- Signal indicator
- 100% of the battery left
- 50% of the battery left
- 10% of the battery left
- The battery indicator of remote
- Pair button
- Charge port

4


反面

PAIR INSTRUCTION


At the first step, the Board and Remote must be paired. Before starting, to ensure the Board and Remote are turn off.



Turn on the board



Press the power button for 5 seconds, then the power button light will flash.



Turn on the remote, then press the pair button. the signal indicator will flash and the power button light will flash with same frequency. Then means the paired successfully.

Push the joystick, forward to test the accelarate and backward to test the brake. After tested all function work normal you can start your riding.

USER MANUAL

5

SPECIFICATION

Deck	Material	8 Layers Maple + 2 Layers bamboo
	Length	1100mm
	Capacity	10000mAh
Battery Pack	Type	Lithium 10S5P
	Weight	2.5G
	Charge Time	6 hours
Motor	Type	6354 High Speed Motor x2
	Power	Dual-motor 1650W*2
Wheel	Material	Pnevumatic tire
	Size	9inch
Wireless Remote Controller	Capacity	200mAh
	Distance	14M
	Charge Time	2 hours
	Max Speed	40KM/H
Complete Skateboard	Max Mileage	20KM
	Max load	200KG
	G.W.	18.5KG
	Net weight	14KG
	Product size	1170*460*240mm
Size	1220*485*290mm	

6

SAFETY INSTRUCTIONS

⚠ The electric skateboard is not a toy, should be treated with appropriate caution. Always practice safety first-as it is possible to lose balance and cause a collision or fall. Ensure that you use the board in a safe appropriate environment, and always wear appropriate safety gear.

🧑‍🚒 Safety Gear: we recommend that you wear full safety gear while riding. Please wear a suitable skateboard helmet, elbow pads, knee pads, and gloves.

👟 Wear shoes: Flipflops or similar loose footwear are not suitable for riding wear.

👤 The skateboard is designed for rider over 10 years old and above.

🚫 Only one person riding for each skateboard at a time. The maximum load of the board is 150kg. Exceeding this weight will compromise the structural integrity of the skateboard, as well as remote and functionality, and may cause board damage, losing control or other breakage.

7

🚫 Please observe your local traffic laws and regulations.

⚠ The board is designed to drive on flat and paved surfaces. Avoid driving on sand, gravel, mud, rugged or open ground. Do not drive on slippery ground, such as snow, ice or wet ground.

🚫 Keep fingers, hairs, and clothing away from motors, wheels and moving parts.

🚫 Do not open or tamper with electronics housing. Electricschock is possible and this also voids the warranty.

8